



BMW Motorrad

bmw-motorrad.com



The Ultimate
Riding Machine

Rider's Manual

R 1200 RT

Vehicle data/dealership details

Vehicle data

Model

Vehicle Identification Number

Colour code

Date of first registration

Registration number

Dealership details

Person to contact in Service department

Ms/Mr

Phone number

Dealership address/phone number (company stamp)

Welcome to BMW

We congratulate you on your choice of a vehicle from BMW Motorrad and welcome you to the community of BMW riders. Familiarise yourself with your new vehicle so that you can ride it safely and confidently in all traffic situations.

About this Rider's Manual

Please read this Rider's Manual carefully before starting to use your new BMW. It contains important information on how to operate the controls and how to make the best possible use of all your BMW's technical features. In addition, it contains information on maintenance and care to help you maintain your vehicle's reliability and safety, as well as its value.

This record of the maintenance work you have had performed on

your vehicle is a precondition for generous treatment of goodwill claims.

If the time comes to sell your BMW, please remember to hand over this Rider's Manual to the new owner. It is an important part of the vehicle.

Suggestions and criticism

If you have questions concerning your vehicle, your authorised BMW Motorrad dealer will gladly provide advice and assistance.

We hope you will enjoy riding your BMW and that all your journeys will be pleasant and safe

BMW Motorrad.

01 40 8 358 111




Table of Contents

1 General instructions	5	Range	39	Cruise-control system	67
Overview	6	Oil level	40	Hill Start Control	69
Abbreviations and symbols	6	Ambient temperature.....	40	Anti-theft alarm (DWA)	70
Equipment	7	Tyre pressures	40	Heating.....	72
Technical data	7	4 Operation.....	43	Front seat	74
Actuality.....	7	Ignition switch/steering lock	44	Rear seat.....	76
2 General views	9	Ignition with Key- less Ride	46	Stowage compartment	78
General view, left side	11	Emergency off switch (kill switch)	52	Central locking	78
General view, right side	13	Lights	52	5 Adjustment.....	83
Underneath the seat	14	Daytime riding light.....	54	Mirrors	84
Multifunction switch, left	15	Hazard warning lights sys- tem	56	Headlight.....	84
Multifunction switch, right	17	Turn indicators	56	Windscreen	84
Instrument panel	18	Multifunction display	57	Instrument panel	85
3 Status indicators	19	On-board computer	61	Clutch	86
Indicator and warning lights	20	Trip distance recorder.....	63	Brakes	86
Meaning of symbols.....	21	Automatic Stability Control (ASC)	63	Spring preload	87
Multifunction display	23	Electronic Suspension Ad- justment (ESA)	64	Damping	88
Warnings	24	Riding mode	65	6 Riding.....	91
Service-due indicator.....	39			Safety instructions	92
				Comply with checklist	94
				Always before riding off	94
				Every 3rd refuelling stop	94
				Starting.....	95

Running in	97	8 Maintenance	119	10 Care	167
Shifting gear	98	General instructions	120	Care products	168
Brakes	99	Standard toolkit	120	Washing the vehicle	168
Parking your motor- cycle	101	Service toolkit	120	Cleaning easily damaged components	169
Refuelling	102	Front-wheel stand	121	Paint care	170
Securing motorcycle for transportation	105	Engine oil	122	Protective wax coating	170
7 Engineering details	107	Brake system	123	Laying up the motor- cycle	170
General instructions	108	Clutch	128	Restoring motorcycle to use	170
Anti-lock brake system (ABS)	108	Coolant	128	11 Technical data	171
Automatic Stability Control (ASC)	111	Tyres	130	Troubleshooting chart	172
Electronic Suspension Ad- justment (ESA)	113	Rims and tyres	130	Threaded fasteners	173
Riding mode	113	Silencer	131	Fuel	175
Tyre pressure monitoring (RDC)	115	Wheels	133	Engine oil	175
Shift assistant	116	Light source	139	Engine	176
drive-off assistant	118	Jump-starting	146	Clutch	177
		Battery	147	Transmission	177
		Fuses	151	Final drive	178
		Diagnostic connector	153	Frame	178
		9 Accessories	155	Chassis and suspension	179
		General instructions	156	Brakes	180
		Power sockets	156	Wheels and tyres	181
		Cases	157		
		Topcase	159		
		Navigation system	162		

Electrical system	183
Anti-theft alarm.....	184
Dimensions	185
Weights	186
Riding specifications	186
12 Service	187
BMW Motorrad Service ...	188
BMW Motorrad Mobility services	188
Maintenance work.....	188
BMW Service	189
Maintenance schedule	191
Confirmation of mainten- ance work	192
Confirmation of service....	206
13 Appendix.....	209
Certificate for electronic immobiliser	210
Certificate for remote con- trol	212
Certificate for Key- less Ride	216
Certificate for tyre pressure control (RDC)	218
14 Index	219

General instructions

Overview	6
Abbreviations and symbols	6
Equipment	7
Technical data	7
Actuality	7

Overview

An important aspect of this Rider's Manual is that it can be used for quick and easy reference. Consulting the extensive index at the end of this Rider's Manual is the fastest way to find information on a particular topic or item. To first read an overview of your motorcycle, please go to Chapter 2. All maintenance and servicing work on the vehicle is documented in Chapter 11. This record of the maintenance work you have had performed on your vehicle is a precondition for generous treatment of goodwill claims. When the time comes to sell your BMW, please remember to hand over this Rider's Manual; it is an important part of the motorcycle.

Abbreviations and symbols



CAUTION Low-risk hazard. Non-avoidance can lead to slight or moderate injury.



WARNING Medium-risk hazard. Non-avoidance can lead to fatal or severe injury.



DANGER High-risk hazard. Non-avoidance leads to fatal or severe injury.



ATTENTION Special notes and precautionary measures. Non-compliance can lead to damage to the vehicle or accessory and, consequently, to voiding of the warranty.



NOTICE Specific instructions on how to operate, control, adjust or look after items of equipment on the vehicle.



Indicates the end of an item of information.

- Instruction.
- » Result of an activity.
- ➔ Reference to a page with more detailed information.
- ◁ Indicates the end of a passage relating to specific accessories or items of equipment.
-  Tightening torque.
-  Technical data.
- OE Optional extras. The vehicles are assembled complete with all the BMW Motorrad optional extras originally ordered.

- OA Optional accessories. You can obtain BMW Motorrad optional accessories through your authorised BMW Motorrad dealer; optional accessories have to be retrofitted to the vehicle.
- EWS Electronic immobiliser.
- DWA Anti-theft alarm (Diebstahlwarnanlage).
- ABS Anti-lock brake system.
- ASC Automatic Stability Control.
- ESA Electronic Suspension Adjustment.
- RDC Tyre pressure monitoring.

Equipment

When you purchased your BMW motorcycle, you chose a model with individual equipment. This Rider's Manual describes the optional extras (OE) offered by BMW and selected optional accessories (OA). You may find that it contains descriptions of items of equipment that you did not select. Please note, too, that your motorcycle might not be exactly as illustrated in this manual on account of country-specific differences.

If your motorcycle contains equipment that has not been described, its description can be found in a separate manual.

Technical data

All dimensions, weights and power ratings stated in the Rider's Manual are quoted to the standards and comply with the


tolerance requirements of the Deutsches Institut für Normung e.V. (DIN). Versions for individual countries may differ.

Actuality

The high safety and quality level of BMW motorcycles is ensured by continuous development work on design, equipment and accessories. Because of this, your motorcycle may differ from the information supplied in the Rider's Manual. Nor can BMW Motorrad entirely rule out errors and omissions. Consequently no claims can be derived from the information, graphics or descriptions.


General views

General view, left side.....	11
General view, right side	13
Underneath the seat	14
Multifunction switch, left	15
Multifunction switch, right.....	17
Instrument panel	18



General view, left side

- 1 Clutch-fluid reservoir
( 128)
- 2 Fuel filler neck ( 102)
- 3 Seat lock ( 74)
- 4 Rear-seat heating ( 73)
- 5 2nd socket
- 6 Stowage compartment, left
( 78)
- 7 Payload table
Table of tyre pressures





General view, right side

- 1 Rider's Manual
- 2 Power socket (►►► 156)
- 3 Brake-fluid tank, front
(►►► 126)
- 4 Stowage compartment,
right (►►► 78)
- 5 VIN (on steering-head
bearing)
Type plate (on steering-
head bearing)
- 6 Coolant level indicator (be-
hind side panel) (►►► 128)
- 7 Oil filler neck (►►► 122)
- 8 To the rear of the engine
spoiler:
Battery (►►► 147)
Positive battery connection
point (►►► 146)
Diagnostic connector
(►►► 153)
- 9 Rear brake-fluid reser-
voir (behind side panel)
(►►► 127)

Underneath the seat


- 1 Adjusting the driver seat height (→ 75)
- 2 Standard toolkit (→ 120)
- 3 Tool for adjusting spring preload (→ 87)
- 4 Fuses (→ 151)





Multifunction switch, left

- 1 High-beam headlight and headlight flasher (➡ 53)
- 2 Daytime riding light (➡ 54)
- 3 Cruise-control system (➡ 67)
- 4 Hazard warning lights system (➡ 56)
- 5 Windscreen adjustment (➡ 84)
- 6 Auxiliary headlights (➡ 53)
- 7 Turn indicators (➡ 56)
- 8 Horn



Multifunction switch, right

- 1 Central locking (→ 78)
- 2 Riding mode (→ 65)
- 3 Emergency off switch (kill switch) (→ 52)
- 4 Start engine (→ 95)


Instrument panel

- 1 Speedometer
- 2 Indicator and warning lights (►► 20)
- 3 Navigation system (►► 162)
- 4 Ambient-light brightness sensor (for adapting the brightness of the instrument lighting)
- 5 Engine speed display
- 6 Release for navigation slot (►► 162)
- 7 Multifunction display (►► 23)
- 8 Trip distance recorder (►► 63)



NOTICE

The brightness of the warning lights and telltale lights, the display and the instrument needle and gauge lighting is adapted automatically to suit ambient brightness. ◀




Status indicators


Indicator and warning lights	20
Meaning of symbols	21
Multifunction display	23
Warnings	24
Service-due indicator	39
Range	39
Oil level	40
Ambient temperature	40
Tyre pressures.....	40

Indicator and warning lights

- 1 ABS (➡ 36)
- 2 ASC (➡ 37)
- 3 Turn indicators
- 4 Fuel reserve (➡ 38)
- 5 Daytime riding light (➡ 54)
- 6 High-beam headlight
- 7 Turn indicators
- 8 - with EU market export^{NV}
Malfunction indicator lamp
Emissions warning (➡ 30)
- 9 DWA (➡ 70)
Telltale light for the radio-operated key (➡ 46)
- 10 Auxiliary headlights (➡ 53)
- 11 Cruise-control system (➡ 67)
- 12 General warning light, in combination with warning symbols on the display (➡ 24)



Meaning of symbols



Meanings of the symbols at position **1**:

 Average fuel consumption since last reset (▬▬▬ 62)

 Current consumption

 Range with fuel now on board (▬▬▬ 39)

 Average speed since last reset (▬▬▬ 62)

 Ambient temperature (▬▬▬ 40)

– with tyre pressure monitoring (RDC)^{OE}

 Tyre pressures (▬▬▬ 40)

 Stopwatch (▬▬▬ 62)

 Travel times (▬▬▬ 62)

 Date (display mode depends on the time format selected) (▬▬▬ 60)

 Oil level (▬▬▬ 40)

 On-board voltage




1 Heated handlebar grips ON

– with seat heating^{OE}


2 Front-seat heating ON

3 Rear-seat heating ON

– with Dynamic ESA^{OE}



- 1 Damping
- 2 Vehicle load



Multifunction display

- 1 Trip distance recorder (➡ 63)
- 2 Warning symbols (➡ 24)
- 3 Menu area (➡ 57)
Audio system
- 4 Automatic daytime riding light (➡ 55)
- 5 Seat heating (➡ 72)
Heated handlebar grips (➡ 72)
– with Dynamic ESA^{OE}
Dynamic ESA range of adjustment (➡ 64)
- 6 On-board computer (➡ 61)
– with tyre pressure monitoring (RDC)^{OE}
Tyre pressure
- 7 Clock (➡ 60)
- 8 Odometer
- 9 Riding mode (➡ 65)
- 10 Hill Start Control (➡ 69)
- 11 Gear indicator; "N" indicates neutral

- 12** Coolant temperature
Fuel level

Warnings

Mode of presentation

Warnings are indicated by the corresponding warning lights.



Warnings for which there is no dedicated warning light are indicated by 'General' warning light **1** showing in combination with a warning symbol such as, for example, **2** appearing in the multifunction display. The 'general' warning light shows yellow or red, depending on the urgency of the warning.

Up to four warning symbols can be displayed at any given time. The status of the 'General' warning light matches the most urgent warning.

The possible warnings are listed on the next pages.

Warnings, overview

Telltale and warning lights

Warning symbols in the display

Meaning

		appears on the display	Outside temperature warning (►►► 29)
 lights up yellow		appears on the display	EWS active (►►► 29)
 lights up yellow		appears on the display	Radio-operated key out of range (►►► 29)
 lights up yellow			Replace the battery of the radio-operated key (►►► 30)
 lights up red		Temperature reading turns red	Coolant temperature too high (►►► 30)
		appears on the display	Engine-oil level too low (►►► 30)
 Malfunction indicator lamp lights up			Emissions warning (►►► 30)
 lights up yellow		appears on the display	Engine fault (►►► 31)

Telltale and warning lights

Warning symbols in the display

Meaning

	flashes yellow		appears on the display	Severe engine fault (→ 31)
	lights up yellow		appears on the display	Front light failure (→ 32)
	lights up yellow		appears on the display	Rear light failure (→ 32)
	lights up yellow		appears on the display	Light failure (→ 32)
			appears on the display	DWA battery weak (→ 32)
	lights up yellow		appears on the display	DWA battery flat (→ 33)
			appears on the display	On-board system voltage low (→ 33)
	lights up yellow		appears on the display	On-board system voltage critical (→ 33)

Telltale and warning lights	Warning symbols in the display	Meaning
 lights up red	 appears on the display	Battery charge voltage insufficient (▣▣▣▶ 34)
 flashes red	 + tyre pressure in red	Tyre pressure outside permitted tolerance (▣▣▣▶ 34)
 lights up yellow	 + "--" or "-- --" appears on the display	Sensor defective or system error (▣▣▣▶ 34)
	 + "--" or "-- --" appears on the display	Signal transmission disrupted (▣▣▣▶ 35)
 lights up yellow	 appears on the display	Battery of tyre-pressure sensor weak (▣▣▣▶ 36)
 flashes		ABS self-diagnosis not completed (▣▣▣▶ 36)
 lights up		ABS fault (▣▣▣▶ 36)
 quick-flashes		ASC intervention (▣▣▣▶ 36)

Telltale and warning lights

Warning symbols in the display

Telltale and warning lights		Warning symbols in the display	Meaning
	slow-flashes		ASC self-diagnosis not completed (→ 37)
	lights up		ASC switched off (→ 37)
	lights up		ASC fault (→ 37)
	lights up yellow	 appears on the display	ESA fault (→ 37)
		 appears on the display	Central locking locked (→ 38)
		 The gear indicator flashes	Gear not calibrated (→ 38)
	briefly shows yellow	 appears on the display	Service overdue (→ 38)
	lights up	Fuel-level reading turns yellow	Fuel down to reserve (→ 38)

Outside temperature warning



appears on the display.

Possible cause:



The air temperature measured at the vehicle is lower than:

approx. 3 °C



WARNING

Risk of black ice also applicable at over 3°C

Risk of accident

- Always take extra care when temperatures are low; remember that there is particular danger of black ice forming on bridges and where the road is in shade.◀
- Ride carefully and think well ahead.

EWS active



lights up yellow.



appears on the display.

Possible cause:

The key being used is not authorised for starting, or communication between key and engine electronics is disrupted.

- Remove all other vehicle keys from the same ring as the ignition key.
- Have the defective key replaced, preferably by an authorised BMW Motorrad dealer.

Radio-operated key out of range

– with Keyless Ride^{OE}



lights up yellow.



appears on the display.

Possible cause:

Communication between R/C key and engine electronics is disrupted.

- Check the battery in the radio-operated key.
 - with Keyless Ride^{OE}
- Replace the battery of the radio-operated key (►► 51).
- Use the emergency key or the radio-operated key with the empty battery to continue your journey.
 - with Keyless Ride^{OE}
- Battery of the radio-operated key is empty, emergency key is not available (►► 49).
- Loss of the radio-operated key, emergency key is available (►► 49).
- Remain calm if the warning symbol appears while you are

riding. You can continue your journey, the engine will not switch off.

- Have the defective radio-operated key replaced by an authorised BMW Motorrad dealer.

Replace the battery of the radio-operated key

 lights up yellow.

 The battery symbol appears on the display.

Possible cause:

- The integral battery in the radio-operated key has lost a significant proportion of its original capacity. There is no assurance of how long the R/C key can remain operational.
- with Keyless Ride^{OE}
- Replace the battery of the radio-operated key (▮▮▮▮ 51).

Coolant temperature too high

 lights up red.

The temperature reading turns red.

ATTENTION

Riding with overheated engine

Engine damage

- Compliance with the information set out below is essential.◀

Possible cause:

The coolant temperature is too high.

- If possible, ride in the part-load range to cool down the engine.
- If the coolant temperature is frequently too high, have the fault rectified as soon as possible by a specialist workshop, preferably an

authorised BMW Motorrad dealer.

Engine-oil level too low

 appears on the display.

Possible cause:

The electronic oil-level sensor has registered an excessively low oil level. The next time you stop for fuel:

- Checking engine oil level (▮▮▮▮ 122).

If the oil level is too low:

- Topping up the engine oil (▮▮▮▮ 123).

Emissions warning

 Malfunction indicator lamp lights up

Possible cause:

The engine control unit has diagnosed a fault which affects the pollutant emissions.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.
- » You can continue riding; pollutant emissions are higher than the threshold values.

Engine fault



lights up yellow.



appears on the display.

Possible cause:

The engine control unit has diagnosed a fault.



WARNING

Unusual ride characteristics when engine running in emergency-operation mode

Risk of accident

- Adapt your style of riding accordingly: avoid accelerating sharply and overtaking.◀
- If you continue to ride be prepared for unusual engine behaviour (low power, poor throttle response, abrupt stalling, etc.).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Severe engine fault



flashes yellow.



appears on the display.

Possible cause:

The engine control unit has diagnosed a severe fault.



WARNING

Engine damage when running in emergency-operation mode

Risk of accident

- Adapt your style of riding accordingly: ride slowly, avoid sharp accelerating and overtaking.
- If possible, have the vehicle brought in and the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.◀
- If you continue to ride be prepared for unusual engine behaviour (low power, poor throttle response, abrupt stalling, etc.).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Front light failure



lights up yellow.



appears on the display.

Possible cause:

Low-beam headlight, high-beam headlight, parking light or front flashing turn indicator defective. The low-beam headlight or one of the LED turn indicators must be replaced.

- Consult a specialist workshop, preferably an authorised BMW Motorrad dealer.
- Replacing bulb for high-beam headlight (►► 141).

Rear light failure



lights up yellow.



appears on the display.

Possible cause:

Rear light, brake light or rear flashing turn indicator defective. The LED rear light must be replaced.

- Consult a specialist workshop, preferably an authorised BMW Motorrad dealer.

Light failure



lights up yellow.



appears on the display.

Possible cause:

A combination of light failures has occurred.

- Consult a specialist workshop, preferably an authorised BMW Motorrad dealer.

DWA battery weak

– with alarm system (DWA)^{OE}



appears on the display.



NOTICE

This error message shows briefly only after the Pre-Ride-Check completes. ◀

Possible cause:

The integral battery in the anti-theft alarm (DWA) has lost a significant proportion of its original capacity. There is no assurance of how long the DWA anti-theft alarm can remain operational if the vehicle's battery is disconnected.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

DWA battery flat

– with alarm system (DWA)^{OE}



lights up yellow.



appears on the display.



NOTICE

This error message shows briefly only after the Pre-Ride-Check completes. ◀

Possible cause:

The integral battery in the anti-theft alarm (DWA) has lost its entire original capacity. There is no assurance that the DWA anti-theft alarm will be operational if the vehicle's battery is disconnected.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

On-board system voltage low



appears on the display.

Generator power is only just sufficient to supply all consumers and charge the battery.

Possible cause:

Too many consumers switched on. On-board system voltage tends to drop particularly at low engine rpm and when the engine is idling.

- When riding at low engine rpm switch off all consumers that are not necessary for road safety (e.g. heated body warmer or auxiliary headlights).

On-board system voltage critical



lights up yellow.



appears on the display.

Generator power is no longer sufficient to supply all consumers and charge the battery. In order to ensure that the engine can be started and the motorcycle ridden, the on-board electronics switch off the electricity supply to the on-board sockets and the auxiliary headlights. In extreme cases the seat heating and the grip heating might also be shut down.

Possible cause:

Too many consumers switched on. On-board system voltage tends to drop particularly at low engine rpm and when the engine is idling.

- When riding at low engine rpm switch off all consumers that are not necessary for road safety (e.g. heated body warmer or auxiliary headlights).

Battery charge voltage insufficient



lights up red.



appears on the display.



WARNING

Discharged battery causes various motorcycle systems to fail, such as lighting, engine or ABS

Risk of accident

- Do not continue your journey. ◀

Battery is not being charged. If you continue to ride the vehicle the on-board electronics will drain the battery.

Possible cause:

Alternator or alternator drive faulty or fuse for alternator regulator has blown.

- Have the fault rectified as quickly as possible by a

specialist workshop, preferably an authorised BMW Motorrad dealer.

Tyre pressure outside permitted tolerance

– with tyre pressure monitoring (RDC)^{OE}



flashes red.



+ the critical tyre pressure shows red.

Possible cause:

Measured tyre pressure is outside permitted tolerance.

- Check the tyre for damage and to ascertain whether the vehicle can be ridden with the tyre in its present condition.

If the vehicle can be ridden with the tyre in its present condition:

- Correct the tyre pressure at the earliest possible opportunity.



NOTICE

Before you adjust tyre pressure, read the information on temperature compensation and adjusting pressure in the section entitled "Engineering details". ◀

- Have the tyre checked for damage by a specialist workshop, preferably an authorised BMW Motorrad dealer.

If you are unsure whether the vehicle can be ridden with the tyre in its present condition:

- Do not continue your journey.
- Notify the breakdown service.

Sensor defective or system error

– with tyre pressure monitoring (RDC)^{OE}



lights up yellow.



+ "---" or "-- ---" appears on the display.

Possible cause:

Motorcycle is fitted with wheels not equipped with RDC sensors.

- Fit wheels and tyres equipped with RDC sensors.

Possible cause:

1 or 2 RDC sensors have failed or a system error has occurred.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Possible cause:

A system error has occurred.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Signal transmission disrupted

– with tyre pressure monitoring (RDC)^{OE}



+ "---" or "-- ---" appears on the display.

Possible cause:

The vehicle did not reach the minimum required speed (►► 115).



RDC sensor is not active

min 30 km/h (The RDC sensor does not transmit its signal to the vehicle until a certain minimum speed has been reached.)

- Increase speed above this threshold and observe the RDC readings. Assume that a permanent fault has not occurred unless the 'General' warning light comes on to accompany

the symptoms. Under these circumstances:

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Possible cause:

Wireless communication with the RDC sensors has been disrupted. Possible causes include radio-communication systems operating in the vicinity and interfering with the link between the RDC control unit and the sensors.

- Move to another location and observe the RDC readings. Assume that a permanent fault has not occurred unless the 'General' warning light comes on to accompany the symptoms. Under these circumstances:
- Have the fault rectified by a specialist workshop, preferably

an authorised BMW Motorrad dealer.

Battery of tyre-pressure sensor weak

– with tyre pressure monitoring (RDC)^{OE}



lights up yellow.



appears on the display.



NOTICE

This error message shows briefly only after the Pre-Ride-Check completes. ◀

Possible cause:

The integral battery in the tyre-pressure sensor has lost a significant proportion of its original capacity. There is no assurance of how long the tyre pressure

control system can remain operational.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

ABS self-diagnosis not completed



flashes.

Possible cause:



ABS self-diagnosis not completed

The ABS function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed for the wheel speed sensors to be checked: 5 km/h)

- Pull away slowly. Bear in mind that the ABS function is not available until self-diagnosis has completed.

ABS fault



lights up.

Possible cause:

The ABS control unit has detected a fault. The ABS function is not available.

- You can continue to ride the vehicle, but make due provision for the fact that the ABS function is not available. Bear in mind the more detailed information on situations that can lead to an ABS fault (➔ 109).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ASC intervention



quick-flashes.

The ASC has detected a degree of instability at the rear wheel and has intervened to re-

duce torque. The indicator and warning light flashes for longer than ASC intervention lasts. This affords the rider visual feedback on control intervention even after the critical situation has been dealt with.

ASC self-diagnosis not completed

 slow-flashes.

Possible cause:

 ASC self-diagnosis not completed

The ASC function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed for the wheel sensors to be checked: min 5 km/h)

- Pull away slowly. Bear in mind that the ASC function is not

available until self-diagnosis has completed.

ASC switched off

 ASC indicator and warning light shows.

Possible cause:

The rider has switched off the ASC system.

- Switch on ASC.

ASC fault

 ASC indicator and warning light shows.

Possible cause:

The ASC control unit has detected a fault. The ASC function is not available.

- You can continue to ride. Bear in mind that the ASC function is not available. Bear in mind the more detailed information on situations that can lead to an ASC fault ( 112).

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ESA fault

 lights up yellow.

 appears on the display.

Possible cause:

The ESA control unit has detected a fault. In this condition, the motorcycle has too much damping and is uncomfortable to drive, especially on roads in poor condition.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Central locking locked

– with central locking system^{OE}



The locked symbol appears on the display.

All locks in the central locking system are locked.

Gear not calibrated

– with Pro shift assistant^{OE}



The gear indicator flashes. The shift assistant Pro is not available.

Possible cause:

– with Pro shift assistant^{OE}

The transmission sensor has not been completely calibrated.

- Engage idle position N and run the engine at standstill for a minimum of 10 seconds to calibrate the idle position.
- Use clutch control to engage all gears and ride for a minimum of 10 seconds in each engaged gear.

- » The gear indicator stops flashing once the transmission sensor has been successfully calibrated.
- Once the transmission sensor has been completely calibrated, shift assistant Pro will operate as described (▮▮▮▮ 116).
- If the calibration process was unsuccessful, have the fault eliminated by a specialist workshop, we recommend a BMW Motorrad Partner.

Service overdue



appears on the display.



General warning light briefly shows yellow after the Pre-Ride-Check.

Possible cause:

A necessary service has not been carried out.

- Have servicing carried out as quickly as possible by a spe-

cialist workshop, preferably an authorised BMW Motorrad dealer.

Fuel down to reserve



lights up.

Fuel-level reading turns yellow.



WARNING

Irregular engine operation or engine shutdown due to lack of fuel

Risk of accident, damage to catalytic converter

- Do not run the fuel tank dry.◀

Possible cause:

The fuel tank contains no more than the reserve quantity of fuel.

	Reserve fuel
approx. 4 l	

- Refuelling (▮▮▮▮ 102).

Service-due indicator



If a service is due, for a brief period after the Pre-Ride-Check the service symbol appears on the display and the service-due date shows instead of the odometer reading.




If the service is overdue the 'General' warning light briefly shows yellow and the service symbol lights up and remains ON.



If the countdown to the next service is less than one month,

service-due date **1** appears on the display.



If the vehicle covers long distances in the course of the year, under certain circumstances it might be necessary to have it serviced at a date in advance of the forecast due date. If the countdown distance to the early service is less than 1000 km, countdown distance **2** appears on the display.



NOTICE

If the service-due indicator appears more than a month before the service date, the current date has to be corrected. This situation can occur if the battery was disconnected. ◀

Range



The range readout indicates how far you can ride with the fuel remaining in the tank. The figure for average consumption used to calculate range is not shown and might not be the same as the average-consumption reading that appears on the display.

You must put at least five litres of fuel into the fuel tank for the new level to be registered correctly. If the sensor cannot register the new level the range readout cannot be updated.

When the motorcycle is propped on its side stand the slight angle of inclination means that the sensor cannot register the fuel level correctly. This is the reason why the range is calculated only when the side stand is in the retracted position.



NOTICE

The calculated range is only an approximate figure. Consequently, BMW Motorrad recommends that you should not try to use the full range before refuelling. ◀

Oil level



The oil-level indicator gives you an indication of the engine oil level.

The preconditions for the oil level check are as follows:

- Engine at operating temperature.
- Engine idling for at least ten seconds.
- Side stand retracted.
- Make sure the motorcycle is upright.

The readings mean:

OK: oil level is correct.

CHECK !: check the oil level the next time you stop for fuel.

— — —: oil level cannot be measured (conditions as stated above not satisfied).

Ambient temperature



When the motorcycle is at a standstill the heat of the engine can falsify the ambient-temperature reading. If the effect

of the engine's heat becomes excessive, "—" temporarily appears on the display.



If ambient temperature drops below the threshold this warning appears, drawing your attention to the risk of black ice forming. The display automatically switches from any other mode to the temperature reading when the temperature drops below this threshold for the first time.




Threshold for ambient temperature

approx. 3 °C

Tyre pressures

- with tyre pressure monitoring (RDC)^{OE}



 The tyre-pressure readings in the multifunction display are temperature-compensated and are always referenced to the following tyre-air temperature:

20 °C

The front tyre pressure is on the left **1**; the reading on the right **2** is the rear tyre pressure. Immediately after the ignition is switched on "-- --" is displayed.



RDC sensor is not active

min 30 km/h (The RDC sensor does not transmit its signal to the vehicle until a certain minimum speed has been reached.)

If the pressure in a tyre drops to a critical level the corresponding status indicator shows red.



The tyre warning symbol also appears on the display.



The "General" warning light flashes red.

The detailed description of BMW Motorrad RDC starts on page (➡ 115).

Operation

Ignition switch/steering lock	44	Cruise-control system	67
Ignition with Keyless Ride	46	Hill Start Control	69
Emergency off switch (kill switch)	52	Anti-theft alarm (DWA)	70
Lights	52	Heating	72
Daytime riding light	54	Front seat	74
Hazard warning lights system	56	Rear seat	76
Turn indicators	56	Stowage compartment	78
Multifunction display	57	Central locking	78
On-board computer	61		
Trip distance recorder	63		
Automatic Stability Control (ASC)	63		
Electronic Suspension Adjustment (ESA)	64		
Riding mode	65		

Ignition switch/steering lock

Keys

You receive 2 ignition keys. Consult the information on the electronic immobiliser (EWS) (►► 45) if a key is lost or mislaid.

One-key system


- Ignition switch/steering lock
- Cases locks
- Stowage-compartment lock
- Tank filler cap
- Seat lock
- Stowage compartment

- with topcase^{OA}
- Topcase

- with audio system^{OE}
- Audio compartment


Lock the handlebars

- Turn the handlebars all the way to left.



- Turn the key to position **1**, while moving the handlebars slightly.
 - » Ignition, lights and all function circuits switched off.
 - » Handlebars are locked.
 - » Key can be removed.

Switching on ignition




- Insert the key in the ignition switch and turn to position **1**.
 - » Side lights and all function circuits are switched on.
 - » Pre-Ride-Check is performed (►► 95)
 - » ABS self-diagnosis is performed (►► 96)
 - » ASC self-diagnosis is performed (►► 97)

Welcome lights

- Switch on the ignition.
 - » The side lights briefly light up.

- with daytime running light^{OE}
 - » The daytime riding lights briefly light up.<
- with LED auxiliary headlights^{OA}
 - » The LED auxiliary headlights briefly light up.<

Switching off ignition



- Turn the ignition key to position **1**.
 - » When the ignition is switched off, the instrument cluster remains switched on for a short time and displays any existing fault messages.
 - » Handlebars not locked.

- » Electrically powered accessories remain operational for a limited period of time.
- » The battery can be recharged via the socket.
- » Key can be removed.

- with daytime running light^{OE}
 - The daytime running light goes out soon after the ignition is switched off.<
- with LED auxiliary headlights^{OA}
 - The LED auxiliary headlights go out soon after the ignition is switched off.<

Electronic immobiliser EWS

The electronic design of the motorcycle allows it to access data stored in the ignition key by means of a ring antenna located in the ignition switch/steering lock. The engine control unit will not permit the engine to be

started unless the key is identified as “authorised”.



NOTICE

A spare key attached to the same ring as the ignition key used to start the engine could “irritate” the electronics, in which case the enabling signal for starting is not issued. The warning with the key symbol appears in the multifunction display. Always keep the spare key separately from the ignition key.<

If you lose a key, you can have it barred by your authorised BMW Motorrad dealer. If you wish to do this, you will need to bring all other keys for the motorcycle with you. The engine cannot be started by a barred key, but a key that has been barred can subsequently be reactivated.

You can obtain extra keys only through an authorised BMW Motorrad dealer. The keys are part of an integrated security system, so the dealer is under an obligation to check the legitimacy of all applications for replacement/extra keys.

Ignition with Keyless Ride

– with Keyless Ride^{OE}

Keys

NOTICE

The telltale light for the radio-operated key flashes while the search for the radio-operated key is in progress.

The telltale light goes out as soon as the radio-operated key or the emergency key is found. The telltale light goes out briefly if the search times out without

the radio-operated key or the emergency key being found. ◀

You receive one radio-operated key and one emergency key. Please consult the information on the electronic immobiliser (EWS) if a key is lost or mislaid (▮▮▮ 45). Ignition, fuel filler cap and anti-theft alarm system all work with the radio-operated key. Seat lock, stowage compartment, top-case and cases can be locked and unlocked manually.

NOTICE

The vehicle cannot be started or the central locking system locked or unlocked if the radio-operated key is not within range (e.g. key inside one of the cases or the topcase).

If the key is taken out of range the ignition is switched off after approximately 1.5 minutes, but

the central locking system is **not** locked.

It is advisable to keep the radio-operated key on your person (e.g. in a jacket pocket) and to have the emergency key with you as an alternative. ◀



Range of the Keyless Ride radio-operated key

approx. 1 m

Lock the handlebars Requirement

The handlebars are turned towards the left. Radio-operated key is within range.



- Press and hold down button **1**.
 - » The steering lock engages with an audible click.
 - » Ignition, lights and all function circuits switched off.
- Briefly press the **1** button to unlock the steering lock.

Switching on ignition Requirement

Radio-operated key is within range.

- There are **two** ways of activating the ignition.

Version 1:

- Short-press button **1**.
 - » Side lights and all function circuits are switched on.
 - with daytime running light^{OE}
 - with Pro Headlight^{OE}
 - » Daytime riding light is switched on.<
 - with LED auxiliary headlights^{OA}
 - » LED auxiliary headlights are switched on.<
 - » Pre-Ride-Check is performed (▣▣▣ 95)

- » ABS self-diagnosis is performed (▣▣▣ 96)
- » ASC self-diagnosis is performed (▣▣▣ 97)

Version 2:

- Steering lock is engaged; press and hold down button **1**.
 - » The steering lock disengages.
 - » Parking lights and all function circuits switched on.
 - » Pre-Ride-Check is performed (▣▣▣ 95)
 - » ABS self-diagnosis is performed (▣▣▣ 96)
 - » ASC self-diagnosis is performed (▣▣▣ 97)

Switching off ignition Requirement

Radio-operated key is within range.



- There are **two** ways of deactivating the ignition.

Version 1:

- Short-press button **1**.
 - » Light is switched off.
 - » Handlebars (steering lock) are not locked.

Version 2:

- Turn the handlebars all the way to left.
- Press and hold down button **1**.
 - » Light is switched off.
 - » The steering lock engages.

Electronic immobiliser EWS

The on-board electronics access the data saved in the radio-operated key via a ring aerial in the R/C ignition lock. The ignition is not enabled for starting until the engine control unit has recognised the radio-operated key as "authorised" for your motorcycle.



NOTICE

A spare vehicle key attached to the same ring as the radio-operated key used to start the engine could "irritate" the electronics, in which case the enabling signal for starting is not issued. The warning with the key symbol appears in the multifunction display. Always keep the spare key separately from the radio-operated key. ◀

If you mislay a radio-operated key you can have the key in question barred by your authorised BMW Motorrad dealer. In order to have a key barred you must bring along all the other keys belonging to the motorcycle.

The engine cannot be started by a barred radio-operated key, but a radio-operated key that has been barred can subsequently be reactivated.


You can obtain emergency/extra keys only through an authorised BMW Motorrad dealer. The radio-operated keys are part of an integrated security system, so the dealer is under an obligation to check the legitimacy of all applications for replacement/extra keys.

Loss of the radio-operated key, emergency key is available

Requirement

Emergency key is available.

- Place the motorcycle on its stand on firm, even ground.
- Please consult the information on the electronic immobiliser (EWS) if a key is lost or mislaid.
- If you happen to loose the radio-operated key during the journey, you can start the vehicle using the emergency key.



- Insert the emergency key **1** in the gap **in the centre** above the instrument cluster **2** (arrow).




Time during which the engine has to be started. The unlocking procedure has to be repeated if this time is allowed to expire.

30 s

- » Pre-Ride Check is performed.
- Key has been recognised.
- Engine can be started.
- Start engine (►► 95).


Battery of the radio-operated key is empty, emergency key is not available

- Place the motorcycle on its stand on firm, even ground.




- Remove screws **2**.
- Ease speaker cover **1** to the right to remove.

– with audio system^{OE}




- Remove screws **1**.
- Carefully remove speaker unit **2**, noting the plug.



- Disconnect plug **1**.◀



- Flip open the key bit.
- Hold the radio-operated key by the key bit **1**.



- Hold the radio-operated key **to the rear** of the instrument


cluster **1 (arrow)**, level with the warning and indicator lights.

 Time during which the engine has to be started. The unlocking procedure has to be repeated if this time is allowed to expire.


30 s

- » Pre-Ride Check is performed.
- Key has been recognised.
- Engine can be started.
- Start engine (▶▶▶ 95).


– with audio system^{OE}



- Connect plug **1**.



- Seat speaker unit **2** in the mount.
- Install screws **1**.<



- Hold speaker cover **1** in position and install screws **2**.


Replace the battery of the radio-operated key

If the radio-operated key does not react when you short-press or long-press a button:

- The battery in the radio-operated key is not at full capacity.
- » Change the battery.



The battery symbol appears on the display.



- Press button **1**.
- » Bitted key flips out.
- Push up battery cover **2**.
- Remove battery **3**.

- Dispose of the old battery in accordance with all applicable laws and regulations; do not attempt to dispose of batteries as domestic waste.



ATTENTION

Unsuitable or incorrectly inserted batteries

Component damage

- Use a battery compliant with the manufacturer's specifications.
- When inserting the battery, always make sure polarity is correct.◀
- Insert the new battery with the positive terminal up.



Battery type

For Keyless Ride-radio-operated key

CR 2032

- Install seal **1** and battery cover **2**.
- » Red LED on the instrument panel flashes.
- » The radio-operated key is again ready for use.

Emergency off switch (kill switch)



- 1** Emergency off switch (kill switch)




WARNING

Operation of the kill switch while riding

Risk of fall due to rear wheel locking

- Do not operate the kill switch when riding. ◀

The emergency off switch is a kill switch for switching off the engine quickly and easily.



- A** Engine switched off
B Normal operating position (run)

Lights

Side light

The side lights switch on automatically when the ignition is switched on.



NOTICE

The side lights place a strain on the battery. Do not switch the ignition on for longer than absolutely necessary. ◀

Low-beam headlight

The low-beam headlight switches on automatically when you start the engine.

High-beam headlight and headlight flasher




- Push switch **1** forward to switch on the high-beam headlight.
- Pull switch **1** back to operate the headlight flasher.

NOTICE

The high-beam headlight can also be switched on when the engine is not running.◀

Parking lights

- Switch off the ignition.



- Immediately after switching off the ignition, push button **1** to the left and hold it in this position until the parking lights come on.
- Switch the ignition on and off again to switch off the parking lights.

Operating LED auxiliary headlights

– with LED auxiliary headlights^{OA}

Requirement

The additional headlights are only active if the low-beam headlight is active; if the daytime riding

light is switched on, it is not possible to switch on the additional headlights.

NOTICE

The auxiliary headlights have approval as fog lights and their use is permissible in bad weather conditions only. Always comply with the road traffic regulations in force in the country in which the vehicle is used.◀



- Press button **1** to switch on the LED auxiliary headlights.



The telltale light shows.



If this warning symbol appears it tells you that the on-board system voltage is low. If applicable, the auxiliary headlights might have been temporarily switched off.

- Press button **1** again to switch off the LED auxiliary headlights.

Daytime riding light

– with daytime running light^{OE}

Manual daytime riding light

Requirement

Automatic daytime riding lights are switched off.



WARNING

Activation of daytime riding light in the dark.

Poorer vision and oncoming traffic dazzled.

- Do not use the daytime running light when it is dark.◀



NOTICE

By comparison with the low-beam headlight, the daytime running light makes the vehicle more visible to oncoming traffic. This improves daytime visibility.◀

- Start engine (▶▶▶ 95).
- Call up the Settings menu and then select **Vehicle**.
- Select the **Day run lights** menu item and switch **Auto. DRL to Off**.



- Press button **1** to switch on the daytime riding light.



The indicator light for the daytime running light illuminates.

- In the dark or in tunnels: Press button **1** again to switch off the daytime riding light and switch on the low-beam headlight.



NOTICE

If the high beam headlight is switched on whilst the daytime running light is switched on, the daytime running light will be switched off after

approx. 2 seconds, and the high beam headlight, low beam headlight, front side lights and, if applicable, the auxiliary headlights will be switched on.

If the high beam headlight is switched off again, the daytime running light is not automatically reactivated, but must be switched on again if required.◀

Automatic daytime riding light

WARNING

The automatic riding light control system cannot replace your personal assessment of lighting conditions, particularly in foggy or misty weather.

Safety risk

- Manually switch on the low-beam headlight in poor lighting conditions.◀

NOTICE

The changeover between daytime running light and low beam headlight including front side lights can be effected automatically.◀

- Call up the Settings menu and then select Vehicle.
- Select the Day run lights menu item and switch Auto. DRL to On.



The symbol for the automatic daytime running light shows in the display.

- » If the ambient brightness decreases below a certain value, the low beam headlight is automatically switched on (e. B. in a tunnel). When sufficient ambient brightness is detected, the daytime riding light is switched back on. When the daytime riding light is active, the daytime riding light symbol

is displayed in the multifunction display.

Manual operation of the light when the automatic system is switched on

- If you press the button for the daytime riding light the daytime riding light is switched off and the low-beam headlight and front side lights are switched on (e. g. when you ride into a tunnel, and the response of the automatic daytime riding light to the change in ambient brightness is delayed). The auxiliary headlight switches on again when the daytime riding light is switched off.
- If you press the button again the daytime riding light is re-activated, in other words the daytime riding light is switched on again when ambient light is bright enough.

Hazard warning lights system


Operating hazard warning flashers

- Switching on ignition (➡ 44).



NOTICE

The hazard warning flashers place a strain on the battery. Do not use the hazard warning flashers for longer than absolutely necessary. ◀




- Press button **1** to switch on the hazard warning flashers.

- » Ignition can be switched off.
- To switch off the hazard warning flashers, switch on the ignition if necessary and press button **1** again.

Turn indicators

Operating the turn indicators

- Switch on the ignition.



- Push button **1** to the left to switch on the left turn indicators.

- Push button **1** to the right to switch on the right turn indicators.
- Operate centre button **1** to cancel the turn indicators.




Turn-indicator cancellation

The turn indicators are cancelled automatically after the defined time and distance.

Multifunction display


Selecting menu



Press button **2** to step through the sequence of menus, starting with the Dynamic ESA menu. Each time you press button **2** you call up the next menu in the sequence; the number of menus depends on the options fitted to the motorcycle.

You also have the option of pressing button **1** for direct access to a favourite menu of your choice.

With the exception of the Audio section, you cannot access the Settings menu unless the vehicle is at a standstill.




The menu you selected appears at position **1**. The submenu you selected **2** has a border.


NOTICE

See the separate Quick Reference Guide for an overview of all menus.◀

Selecting menu item




Use Multi-Controller **1** to move the cursor in a menu.




An arrow **1** at the top or bottom of the display indicates that there are other items in this menu that you can view by turning the Multi-Controller in the corresponding direction. If arrow **2** appears in the cursor, you can call up a submenu by pressing the Multi-Controller to the right (for information on the different meaning in relation to average values and list selections, see (▶▶ 58)).

Setting parameters



Direct selection

If you move the cursor to a menu item that requires no other settings, your selection goes active right away.



Resetting values


You can reset average values marked with an arrow **1** by long-pressing the Multi-Controller to the right.



Selecting from a list


A circle **1** beside each selectable item means that the items are part of a selection list. A circle with a dot indicates the item that is currently selected.

If you want to change the selection move the cursor to some other item in the list and press the Multi-Controller to the right to either activate or deactivate the parameter you selected.



Setting numerical values

If there are one or more numerical values between the arrows **1**, you can increase the values by turning the Multi-Controller up or reduce the values by turning it down. You can toggle between the values by pressing the Multi-Controller to the right or left.




Setting relative values

A bar indicator enables you to set a value in a range between two limits. Turn the Multi-Controller up to increase the setting or down to reduce the setting.

Exiting menu



Arrow **1** appears when you are in a submenu.



Press Multi-Controller **1** to the left to return to the next highest menu; press MENU button **2** to return to the main menu.

If you want to hide the menus, press Multi-Controller **1** to the left in a main menu.

Selecting favourite menu

- Select the main menu of your choice.



- Press and hold down button **1**.
 The lozenge appears to the right of the selected menu.

» The menu you have selected will subsequently be called up whenever you press button **1**.

Adapting mode of presentation

- Switch on the ignition.
- Call up the Settings menu and select the User menu item.

The settings you can choose are as follows:

- Language: display language (German, English, Spanish, Italian, French, Dutch, Portuguese)
- Time format - 24h / 12h: time in 12 hour format (12 h) or 24 hour format (24 h)
- Time format - Date format: date in Day.Month.Year format (dd . mm . yy) or Month/Day/Year format (mm / dd / yy)
- Time format - GPS time: transfers GPS time and GPS date from the installed navigation system (On), (Off)
- Brightness: display and needle brightness
- Start logo: displays the start logo after switching on the ignition (On), (Off)
- Fact. settings: restore factory default settings (if Reset! is displayed, press


and hold the Multi-Controller towards the right)

- Background: displayed if the radio is switched off: Empty: off, Logo: logo (RT), Speedo: digital speed.
- Use the Multi-Controller to configure the desired settings.

On-board computer

Select display

- Call up the Info menu and then select the desired information.



The following items of information can be displayed in panel 1:

- ØConsump.: average consumption
- Consumption: current consumption
- Range: range with remaining fuel
- ØSpeed: average speed
- Temperature: ambient temperature
- Tire pressure: tyre pressure
- Stopwatch: stopwatch
- Travel times: travelling times

- Date: current date
- oil level: engine oil level
- Elec. voltage: vehicle voltage
- Off: no display

Resetting the average values

- Call up the Info menu and then select the average value you would like to reset.
- Push the Multi-Controller to the right and hold it in this position until the average value is reset.

Operate stopwatch


- Call up the Info menu and then select the Stopwatch menu item.



- With the stopwatch stopped, push Multi-Controller **1** to the right to start the stopwatch.
 - » The stopwatch continues timing even if you select some other reading or switch off the ignition.
- When the stopwatch is running, push Multi-Controller **1** to the right to stop the stopwatch.
- Push Multi-Controller **1** to the right and hold it in this position to reset the stopwatch.

Measuring travel times

- Call up the Info menu and then select the Travel times menu item.




- Push Multi-Controller **1** to the right and hold it in this position to reset the travel time.
 - » Timing continues even if you select some other reading or switch off the ignition.
- ▶ Time during which the motorcycle was on the move since the last reset.

II Time during which the motorcycle was at a standstill since the last reset.

Trip distance recorder

Selecting the trip distance recorder

- Switch on the ignition.



- Call up the Trip menu using the Multi-Controller **1** and then select the desired trip distance recorder **2**.

The following counters can be displayed:

- Trip distance recorder 1 (Trip 1)
- Trip distance recorder 2 (Trip 2)
- Automatic trip distance recorder (Trip Auto.), automatically resets once the ignition has been switched off for eight hours.

Resetting trip distance recorder

- Switch on the ignition.
- Select the desired trip distance recorder.



- Push Multi-Controller **1** to the right and hold it in this position until trip distance recorder **2** is reset.


Automatic Stability Control (ASC)

Switching ASC function off and on

- Switch on the ignition.
- Call up the Settings menu and then select the ASC menu item.

 **NOTICE**

This menu cannot be called up while the motorcycle is on the move. ◀



- Select **Off (once)** to switch off ASC once and reactivate it when the ignition is switched on the next time.



If the ASC is switched off, the ASC indicator and warning light lights up.

- Select **On** to switch on the ASC. Alternatively: Switch the ignition off and then on.



The ASC indicator and warning light goes out. If self-diagnosis has not been completed, the ASC indicator and warning light starts flashing.

Electronic Suspension Adjustment (ESA)

– with Dynamic ESA^{OE}

Dynamic ESA range of adjustment

Dynamic ESA enables you to adjust your motorcycle's suspension to suit the load and the road conditions.

Via ride height sensors, Dynamic ESA detects the movements in the chassis and suspension and responds to the same by adjusting the damper valves. The chassis and suspension will thus be adapted to the characteristics of the terrain.

You can set the damping to a harder (**HARD**) or softer (**SOFT**)

setting than the basic setting (**NORMAL**).

ESA calibrates itself at regular intervals when stationary with the engine running to ensure the correct operating principle of the system. During this calibration, chassis and suspension adjustment is not possible.

– with Pro riding modes^{OE}

The suspension setting depends on the riding mode selected. The damping defined by the riding mode can be changed by the rider.


Adjusting the chassis and suspension

- Start the engine.


NOTICE

You can adjust the damping characteristic while the motorcycle is on the move. ◀

- Call up the ESA menu.




The possible settings for the damping action are displayed.

- **Soft**: comfortable damping action
- **Normal**: normal damping action
- **Hard**: sporty damping action

- Select the damping characteristic you want or move the cursor down to set the vehicle load.

NOTICE

The load cannot be set while the motorcycle is in motion. ◀



The range of adjustment for the load will be displayed.



Solo mode



Solo mode with luggage



Operation with pillion (and luggage)

- Select the vehicle load variant you want.

» The suspension adjusts to suit the new setting and the Dynamic ESA reading changes accordingly. The symbols for vehicle load and damping characteristic are greyed while adjustment is in progress.

Riding mode

Using the riding modes

BMW Motorrad has developed 3 operational scenarios for your motorcycle from which you can select the scenario suitable for your situation:

- Riding on a rain-wet road surface.
- Riding on a dry road surface.
- with Pro riding modes^{OE}
- Dynamic riding on a dry road surface.

The interplay of engine torque, throttle response, ABS control and ASC control is optimised for each of these three scenarios.

– with Dynamic ESA^{OE}

The suspension setting also adapts to the selected scenario.

Setting riding mode

- Switching on ignition (➔ 44).



- Press button **1**.



NOTICE

See the section entitled "Engineering details" for more inform-

ation on the various ride modes that can be selected.◀



The selection arrow **2** and the active riding mode **1** are displayed.



- Press button **1** as often as necessary until the required riding mode is indicated next to the selection arrow.

The following ride modes can be selected:

- RAIN: For riding on a rain-wet road surface.
- ROAD: For riding on a dry road surface.

– with Pro riding modes^{OE}

» The following riding mode can also be selected:

- DYNA: For dynamic riding on a dry road surface.◀

- » With the motorcycle at a standstill, the selected mode is activated after approximately two seconds.
- » The newly selected riding mode is activated as you ride only if the throttle twistgrip is returned to the idle position.
- » Following activation of the new riding mode the symbols for coolant temperature and fuel level reappear in the display.
- » The mode selected in this way is retained with the engine-characteristic, ABS, ASC and Dynamic ESA adaptation settings even after the ignition has been switched off.

Cruise-control system

– with cruise control^{OE}

Switching on cruise control



- Slide switch **1** to the right.
- » Button **2** is enabled for operation.

Saving road speed



- Briefly push button **1** forward.

 Adjustment range for cruise control (gear-dependent)

10...210 km/h

SET Telltale light for cruise control shows.


- » The motorcycle maintains your current cruising speed and the setting is saved.

Accelerating



- Briefly push button **1** forward.
 - » Speed is increased by approx. 2 km/h each time you push the button.
- Push button **1** forward and hold it in this position.
 - » The motorcycle accelerates steplessly.
 - » The current speed is maintained and saved if button **1** is not pushed again.

Decelerating



- Briefly push button **1** back.



Reducing speed

Speed is reduced each time you push the button.


2 km/h

- Push button **1** back and hold it in this position.
 - » The motorcycle decelerates steplessly.
 - » The current speed is maintained and saved if button **1** is not pushed again.

Deactivate cruise control

- Brake, pull the clutch lever or turn the throttle twistgrip (close the throttle by turning the twistgrip back past the idle position) to deactivate the cruise-control system.
 - » Telltale light for cruise control goes out.

Resuming former cruising speed




- Briefly push button **1** back to return to the speed saved beforehand.

NOTICE

Opening the throttle does not deactivate the cruise-control system. If you release the twistgrip the motorcycle will decelerate only to the cruising speed saved in memory, even though you might have intended slowing to a lower speed.◀

SET Telltale light for cruise control shows.

Switching off cruise control



- Slide switch **1** to the left.
 - » The system is deactivated.
 - » Button **2** is disabled.

Hill Start Control

– with Hill Start Control^{OE}

Hill Start Control Operation

ATTENTION

Switching off the engine or ignition, extending the side stand, timeout (approx. 20

minutes) or in the event of a fault

Hill Start Control brake failure


- It is essential to apply the brakes manually to hold the vehicle.◀

NOTICE

Hill Start Control is purely a comfort system to facilitate holding the machine and pulling way on uphill gradients and should not be confused with a parking brake.◀

NOTICE

See the section entitled "Engineering details" for more information on Hill Start Control.◀



- Firmly pull and then release handbrake lever **1**.



Telltale light for Hill Start Control appears in the display.

- » Hill Start Control is activated.
- Pull handbrake lever **1** again to switch off Hill Start Control.



NOTICE

Hill Start Control is deactivated automatically when the motorcycle pulls away.◀

- The 'General' warning light and the indicator light show briefly

in the display and the indicator light for Hill Start Control goes out when the brakes are fully released.

- » Hill Start Control is switched off.

Anti-theft alarm (DWA)

Activation

- with alarm system (DWA)^{OE}
- Switching on ignition (▶▶▶ 44).
- DWA Adapting (▶▶▶ 71).
- Switch off the ignition.
- » If the alarm system is activated, then the alarm system will be automatically activated when the ignition is switched off.
- » Activation takes approximately 30 seconds to complete.
- » Turn indicators flash twice.
- » Confirmation tone sounds twice (if programmed).
- » Anti-theft alarm is active.


Alarm signal

A DWA alarm can be triggered by:

- motion sensor
- an attempt to use an unauthorised vehicle key to switch on the ignition
- disconnection of the DWA anti-theft alarm from the motorcycle's battery (DWA internal battery in the anti-theft alarm provides power - alarm tone only, the turn indicators do not flash)

All functions are sustained even if the internal battery of the DWA anti-theft alarm system is flat; the only difference is that an alarm cannot be triggered if the system is disconnected from the motorcycle's battery.

An alarm lasts for approximately 26 seconds. While an alarm is in progress an alarm tone sounds and the turn indicators flash. The type of alarm tone can be set by an authorised BMW Motorrad dealer.



Cancel activated alarms at any time by operating the **2** button on the remote key or the radio-operated key without deactivating the DWA.

If an alarm was triggered while the motorcycle was unattended, the rider is notified accordingly by an alarm tone sounding once when the ignition is switched on. The DWA LED then indicates the reason for the alarm for one minute.

Light signals issued by the DWA LED:

- Flashes 1x: Motion sensor 1
- Flashes 2x: Motion sensor 2
- Flashes 3x: Ignition switched on with unauthorised vehicle key
- Flashes 4x: Disconnection of the DWA anti-theft alarm from the motorcycle's battery
- Flashes 5x: Motion sensor 3

Deactivation


- with alarm system (DWA)^{OE}
 - Kill switch in operating position (run).
 - Switch on the ignition.

- » Turn indicators flash once.
- » Confirmation tone sounds once (if programmed).
- » Anti-theft alarm is deactivated.

DWA Adapting

– with alarm system (DWA)^{OE}

- Call up the Settings menu and select the Vehicle - Alarm syst. menu item.



The following settings are available:

- Automatic - On: alarm system activated automatically after switching off the ignition.

- Automatic - Off: alarm system must be activated using the remote key after having switched off the ignition.
- Alarm tone: alarm tone type.
- Operat. tone - On: confirmation by the turn indicators and a sound after having switched the alarm system on/off.
- Operat. tone - Off: confirmation by the turn indicators only; after having switched the alarm system on/off.
- Configure the desired settings using the Multi-Controller.

Heating

Operating the heated handlebar grips


- Start the engine.



NOTICE


The heating in the heated handlebar grips can be activated only when the engine is running.◀

- Call up the Handle heat. menu.



The grips have five-stage heating. Stage five is for heating the grips quickly: it is advisable to switch back to a lower stage as soon as the grips are warm.

- Select the heating stage you want.



Symbol **1** appears on the display, indicating that the handlebar grip heating is ON.

Front-seat heating

- with seat heating^{OE}


- Start the engine.



NOTICE


Seat heating can be activated only when the engine is running.◀

- Call up the Seat heating menu.



The front seat has five-stage heating. Stage five is for heating the seat quickly: it is advisable to switch back to a lower stage as soon as the seat is warm.

- Select the heating stage you want.



Symbol **1** appears on the display, indicating that the seat heating is ON.



If this warning symbol appears it tells you that the on-board system voltage is low. If applicable, the seat heating might have been temporarily switched off.

Rear-seat heating

– with seat heating^{OE}

- Start the engine.




NOTICE

Seat heating can be activated only when the engine is running. ◀




- Set switch **1** to the desired heating stage.



The rear seat has two-stage heating. Stage two is for heating the seat quickly: it is advisable to switch back to stage one as soon as the seat is warm.

- **2** Switch centred: Heating off.
- **3** One-dot section of switch pressed: 50 % heating power.
- **4** Two-dot section of switch pressed: 100 % heating power.




Symbol **1** appears on the display, indicating that the rear seat heating is ON.



If this warning symbol appears it tells you that the on-board system voltage is low. If applicable, the seat heating might have been temporarily switched off.

Front seat Removing front seat



- Turn ignition key **2** clockwise.
- Slightly raise front seat **1** at the back.




- Work front seat **1** to the rear to disengage it from seat retainer bridge **3** and remove.

– with seat heating^{OE}


- Disconnect plug **2** for the seat heating.<
- Remove the front seat and place it, upholstered side down, on a clean, dry surface.

Installing front seat

– with seat heating^{OE}



- Connect plug **1** of the seat heating.<




- Position the front seat with mounts **2** in rubber buffers **1** on left and right.
- Lower the rear of the front seat and engage the seat in the latching mechanism.

Adjusting front-seat height

- Removing front seat (➡ 74).




- Push latch **1** forward and remove adjusting plate **2**.



- Turn the adjusting plate to position **L** for the lower seat height.

- Turn the adjusting plate to position **H** for the higher seat height.




- Insert the adjusting plate in the desired position into mounts **2** and then push it into latch **1**.
- Installing front seat (☛ 75).

Rear seat


Removing rear seat

- Switch off the ignition.
- Removing front seat (☛ 74).



- Remove screws **1**.
- Pull the rear seat slightly forward and lift the seat slightly.

– with seat heating^{OE}



- Disconnect plug **1** of the seat heating and remove the rear seat.<
- Place the seat, upholstered side down, on a clean surface.

Install the rear seat

– with seat heating^{OE}



- Connect plug **1** of the seat heating.<




- Lay the rear seat on mounts **1**.



- Install screws **1**.

Stowage compartment

Using left stowage compartment



- Use the ignition key to open or close lock **1** of the stowage compartment.
- To open the lid, push the unlocked lock barrel downwards.



ATTENTION

High temperatures in the storage compartments, particularly in summer

Damage to objects stowed away, particularly electronic devices,

such as mobile phones and MP3 players

- Consult the operating instructions of your electronic device and check for possible usage restrictions.◀
- In summer, do not place heat-sensitive objects in the storage compartments.

Using right stowage compartment

– with audio system^{OE}



- Use the ignition key to open or close lock **1** of the stowage compartment.

- To open the lid, push the unlocked lock barrel downwards.



ATTENTION

High temperatures in the storage compartments, particularly in summer

Damage to objects stowed away, particularly electronic devices, such as mobile phones and MP3 players

- Consult the operating instructions of your electronic device and check for possible usage restrictions.◀
- In summer, do not place heat-sensitive objects in the stowage compartments.

Central locking Lock

– with central locking system^{OE}



- Switch on the ignition and press button **1**.

NOTICE

Only vehicles without Keyless Ride are shipped accompanied by a separate remote control for the central locking system and the alarm system. ◀

- Alternatively: Press button **2** on the remote control or the radio-operated key.
 - » The stowage compartment in the left side panel and the cases are locked.

- with audio system^{OE}
 - » The stowage compartment in the right side panel is locked. ◀
- with topcase^{OA}
 - » The topcase is locked. ◀
 - » These locks cannot subsequently be unlocked manually.



The locked symbol appears on the display.

- with alarm system (DWA)^{OE}
 - » The functions of the remote control for the anti-theft alarm are described in the corresponding section. ◀

Unlocking

- with central locking system^{OE}



- Switch on the ignition and press button **1**.
- Alternatively: Press button **2** on the remote control or the radio-operated key.
 - » The stowage compartment in the left side panel and the cases are unlocked.
 - » The stowage compartment in the right side panel is unlocked.
- with topcase^{OA}
 - » The topcase is unlocked. ◀
 - » Once a lock has been locked manually it subsequently has to be unlocked manually as well.

- with alarm system (DWA)^{OE}
- » The functions of the remote control for the anti-theft alarm are described in the corresponding section.◀

Emergency unlocking

- with central locking system^{OE}

If the central locking system refuses to unlock, you can open the cases, topcase and stowage compartments manually. The procedure is as follows:

- Removing cases (➡ 158).
- Open cases (➡ 157).



- First turn the key in the topcase lock 45° past the LOCK position, then turn it to the dot position and press in the lock barrel.
- » The release lever pops open.


Logon of remote controls

- with central locking system^{OE}
- with alarm system (DWA)^{OE}
- without Keyless Ride^{OE}

If a remote control has been mislaid and a replacement acquired or if you are going to use an additional remote control, you must

invariably log on all the remote controls in the set.


- Enable logon of the remote controls as follows:
- Switch on the ignition.



- Press button **2** on the remote control three times.
- » One acoustic signal sounds.
- Within ten seconds, switch off the ignition.

You can now proceed to log on all the remote controls.

- Step through the following procedure with each remote control in turn:



- Press and hold down buttons **1** and **2** until LED **3** stops flashing.

» LED **3** flashes for approx. 10 seconds.

- Release buttons **1** and **2**.

» LED **3** lights up.

- Press button **1** or button **2**.

» One acoustic signal sounds, LED **3** goes out.

To complete logon:

- Switch off the ignition.

» Three acoustic signals sound.

» Logon is also ended in the following situations:

- 4 remote control units have been logged on.
- No button pressed within approximately 30 seconds of logon on the first remote control.


Synchronise the remote controls

- with central locking system^{OE}
- with alarm system (DWA)^{OE}
- without Keyless Ride^{OE}

If the central locking system stops responding to the signals from a remote control, the unit in question has to be synchronised. This can happen, for example, if the buttons on the remote control were pressed too frequently while the remote control was out of range of the anti-theft alarm.

- The procedure for synchronising the remote controls is as follows:

- Switch on the ignition.



- Press and hold down buttons **1** and **2** until LED **3** stops flashing.

» LED **3** flashes for about ten seconds.

- Release buttons **1** and **2**.

» LED **3** lights up.

- Press button **1** or button **2**.


» LED **3** goes out.

Replacing battery of remote control

- with central locking system^{OE}
- with alarm system (DWA)^{OE}
- without Keyless Ride^{OE}

If you press a button on the remote control and the LED does not show or lights up only briefly:

- Replace the battery of remote control.



- Open battery-compartment cover **1**.
- Dispose of the old battery in accordance with all applicable laws and regulations; do not

attempt to dispose of batteries as domestic waste.



ATTENTION

Unsuitable or incorrectly inserted batteries

Component damage

- Use a battery compliant with the manufacturer's specifications.
- When inserting the battery, always make sure polarity is correct. ◀
- Insert the new battery with the positive terminal up.




Battery type

For remote control of central locking

CR 1632

- » The LED on the remote control lights up; the remote control has to be synchronised.



- Press button **1** twice.
 - » LED **3** flashes for a few seconds.
 - » The remote control is again ready for use.

Adjustment

Mirrors	84
Headlight	84
Windscreen	84
Instrument panel	85
Clutch	86
Brakes	86
Spring preload	87
Damping	88

Mirrors

Adjusting mirrors



- Pivot the mirror to the correct position by pressing gently at the edge of the glass.

Headlight

Headlight beam throw and spring preload

Headlight beam throw is generally kept constant when spring preload is adjusted to suit load. Spring preload adjustment might not suffice only if the motorcycle is very heavily loaded. Under

these circumstances, headlight beam throw has to be adjusted to suit the weight carried by the motorcycle.




NOTICE

If there are doubts about the correct headlight beam throw, have the setting checked by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

Adjusting headlight beam throw

Requirement

If, for a high load, the adjustment of the spring pre-load is no longer sufficient not to dazzle oncoming traffic:



- The headlight beam-throw is adjusted via an engage pivot lever.
- **A** Setting for light load (one-up)
- **B** Position for riding one-up with luggage
- **C** Setting for high load (two-up)

Windscreen

Adjusting windscreen

- Switch on the ignition.
- » When you pull away the windscreen automatically returns to

the position it was in before the ignition was switched off.



- Press top section of button **1** to raise the windscreen.
- Press bottom section of button **1** to lower the windscreen.
- Switch off the ignition.
 - » The windscreen automatically moves to the bottom limit position.
 - » If the windscreen encounters resistance before it reaches its limit position the pressure-sensitive finger guard system goes active. The windscreen is stopped and raised slightly.

After a delay of a few seconds the windscreen again attempts to move to the bottom limit position.


There is no guarantee that the pressure-sensitive finger guard system will function correctly if a windscreen that does not have BMW Motorrad approval is installed.

- Under these circumstances: Before switching off the ignition always check that there is nothing to obstruct movement of the windscreen.

Instrument panel Adjusting instrument panel



Do not attempt to adjust the position of the instrument panel unless the vehicle is at a standstill.◀



- Press instrument panel **1** firmly at top or bottom edge, as applicable, to move it to the desired position. Be sure to apply pressure midway along the edge in order to ensure that movement is the same at both sides.

Clutch

Adjusting the clutch lever




WARNING

Adjusting the clutch lever while riding

Risk of accident

- Do not attempt to adjust the clutch lever unless the motorcycle is at a standstill. ◀



- Turn knob **1** to the desired position.



NOTICE

The adjuster is easier to turn if you push the clutch lever forward. ◀

- » Four settings are possible:
- Position 1: Smallest span between handlebar grip and clutch lever.
 - Position 4: Largest span between handlebar grip and clutch lever.

Brakes

Adjusting the front brake lever




WARNING

Adjusting the brake lever while riding

Risk of accident

- Do not attempt to adjust the brake lever unless the motorcycle is at a standstill. ◀



- Turn knob **1** to the desired position.



NOTICE

The adjuster is easier to turn if you push the brake lever forward. ◀

- » Four settings are possible:
- Position 1: Smallest span between handlebar grip and brake lever.
 - Position 4: Largest span between handlebar grip and brake lever.

Spring preload

Adjustment

It is essential to set spring preload of the rear suspension to suit the load carried by the motorcycle. Increase spring preload when the vehicle is heavily loaded and reduce spring preload accordingly when the vehicle is lightly loaded.


Adjusting spring preload for rear wheel

WARNING


Adjusting spring preload while riding.

Risk of accident

- Do not attempt to adjust spring preload unless the motorcycle is at a standstill.◀
- Make sure the ground is level and firm and place the motorcycle on its stand.



- Ease out bottom of cover **1** at position **2**.
- In order not to damage the cover or the mounts, disengage the cover at positions **3**.



WARNING

Spring preload setting and spring-strut damping setting not matched.

Impaired handling.

- Adjust spring-strut damping to suit spring preload.◀
- If you want to increase spring preload, use tool **2** (on-board toolkit) to turn knob **1** clockwise.
- If you want to reduce spring preload, use tool **2** to turn knob **1** counter-clockwise.



Basic setting of spring preload, rear

– without Dynamic ESA^{OE}

Turn the adjuster knob as far as it will go counter-clockwise. (One-up without luggage)

Turn the adjuster knob as far as it will go counter-clockwise, then back it off 10 turns in the clockwise direction. (One-up with luggage)

Turn the adjuster knob as far as it will go clockwise. (Two-up with luggage)



- Seat the cover in mount **2** and press it into mounts **1**.


Damping Adjustment

Damping must be adapted to suit the surface on which the motor-cycle is ridden and to suit spring preload.

- An uneven surface requires softer damping than a smooth surface.
- An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.

Adjusting the damping characteristic for rear wheel

- Make sure the ground is level and firm and place the motor-cycle on its stand.
- Set the damping from the left-hand vehicle side.



- If you want to increase damping, turn adjusting screw **1** clockwise.
- If you want to reduce damping, turn adjusting screw **1** counter-clockwise.



Basic setting of rear-suspension damping characteristic

– without Dynamic ESA^{OE}

Turn the adjuster knob as far as it will go in the clockwise direction, then back it off 6 clicks in the counter-clockwise direction. (One-up without luggage)

Turn the adjuster knob as far as it will go in the clockwise direction, then back it off 4 clicks in the counter-clockwise direction. (One-up with luggage)

Turn the adjuster knob as far as it will go in the clockwise direction, then back it off 2 clicks in the counter-clockwise direction. (Two-up with luggage)◁

Riding

Safety instructions	92
Comply with checklist.....	94
Always before riding off	94
Every 3rd refuelling stop	94
Starting	95
Running in	97
Shifting gear	98
Brakes	99
Parking your motorcycle	101
Refuelling	102
Securing motorcycle for transportation	105

Safety instructions

Rider's equipment

Do not ride without the correct clothing! Always wear:

- Helmet
- Motorcycling jacket and trousers
- Gloves
- Boots

This applies even to short journeys, and to every season of the year. Your authorised BMW Motorrad dealer will be glad to advise you on the correct clothing for every purpose.

Loading



WARNING


Handling adversely affected by overloading and imbalanced loads

Risk of falling

- Do not exceed the permissible gross weight and be sure to comply with the instructions on loading. ◀
- Adjusting spring preload setting and damping to the total weight.
- Ensure that the case volumes on the left and right are equal.
- Make sure that the weight is uniformly distributed between right and left.
- Pack heavy items at the bottom and toward the inboard side.
- Note the maximum permissible payload and the speed limit for riding with cases fitted, as stated on the label inside the case (see also the section entitled "Accessories").
- Note the maximum permissible payload and the speed limit for riding with topcase fitted, as stated on the label inside

the case (see also the section entitled "Accessories").

- with tank rucksack^{OA}
- Note the maximum permissible payload of the tank rucksack.



Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle:

- Settings of the spring-strut and shock-absorber system
- Imbalanced load
- Loose clothing
- Insufficient tyre pressure
- Poor tyre tread
- Etc.

Maximum permissible speed with winter tyres



Maximum speed of the motorcycle is higher than the permissible maximum rated speed of the tyres

Risk of accident due to tyre damage at high speed

- Comply with the tyre-specific speed restrictions.◀

Always bear the maximum permissible speed of the tyres in mind when riding a motorcycle fitted with winter tyres.

Affix a label stating the maximum permissible speed to the instrument panel in the rider's field of vision.

Risk of poisoning

Exhaust fumes contain carbon monoxide, which is colourless and odourless but highly toxic.



Exhaust gases adversely affecting health

Risk of asphyxiation

- Do not inhale exhaust fumes.
- Do not run the engine in an enclosed space.◀

Risk of burn injury



Engine and exhaust system become very hot when the vehicle is in use

Risk of burn injury

- When you park the vehicle make sure that no-one and no objects can come into contact with the hot engine and exhaust system.◀

Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage.

The following guidelines must be observed:

- Do not run the fuel tank dry.
- Do not attempt to start or run the engine with a spark-plug cap disconnected.
- Stop the engine immediately if it misfires.
- Use only unleaded fuel.
- Comply with all specified maintenance intervals.



Unburned fuel in catalytic converter

Damage to catalytic converter

- Note the points listed for protection of the catalytic converter.◀

Risk of overheating



ATTENTION

Engine running for prolonged period with vehicle at standstill

Overheating due to insufficient cooling; in extreme cases vehicle fire

- Do not allow the engine to idle unnecessarily.
- Ride away immediately after starting the engine.◀

Tampering



ATTENTION

Tampering with the motorcycle (e.g. engine management ECU, throttle valves, clutch)

Damage to the affected parts, failure of safety-relevant functions, voiding of warranty

- Do not tamper with the vehicle in any way that could result in tuned performance.◀

Comply with checklist

- At regular intervals, use the checklist below to check your motorcycle.

Always before riding off

- Check operation of the brake system.
- Check operation of the lights and signalling equipment.
- Checking clutch function (▣▣▣ 128).
- Checking tyre tread depth (▣▣▣ 131).
- Checking tyre pressure (▣▣▣ 130).
- Check security of cases and luggage.

- without Dynamic ESA^{OE}
- Adjusting spring preload for rear wheel (▣▣▣ 87).
- Adjusting the damping characteristic for rear wheel (▣▣▣ 88).◀
- with Dynamic ESA^{OE}
- Adjusting the chassis and suspension (▣▣▣ 64).◀

Every 3rd refuelling stop

- Checking engine oil level (▣▣▣ 122).
- Checking front brake pad thickness (▣▣▣ 124).
- Check the rear brake pad thickness (▣▣▣ 125).
- Checking brake-fluid level, front brakes (▣▣▣ 126).
- Checking the brake-fluid level, rear brakes (▣▣▣ 127).
- Check coolant level (▣▣▣ 128).

Starting

Start engine

- Switch on the ignition.
- » Pre-Ride-Check is performed (▶▶▶ 95)
- » ABS self-diagnosis is performed (▶▶▶ 96)
- » ASC self-diagnosis is performed (▶▶▶ 97)
- Select neutral or, if a gear is engaged, pull the clutch lever.



NOTICE

You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if you start it with the gearbox in neutral and then engage a gear before retracting the side stand.◀

- When starting a cold engine at low ambient temperatures: disengage the clutch and turn

the twistgrip slightly to open the throttle.



- Press starter button **1**.



NOTICE

The start attempt is automatically interrupted if battery voltage is too low. Recharge the battery before you start the engine, or use jump leads and a donor battery to start.

See the subsection on jump starting in "Maintenance" for more details.◀

- » The engine starts.

- » If the engine refuses to start, consult the troubleshooting chart in the section entitled "Technical data". (▶▶▶ 172)

Pre-Ride-Check

The instrument panel runs a test of the 'General' warning light when the ignition is switched on: this is the Pre-Ride-Check.

Phase 1



lights up yellow.

- » Needles of the instruments move once from their start-of-scale to end-of-scale positions.

Phase 2



lights up red.

Phase 3

- » 'General' warning light goes out and display switches to operational information.
- » The malfunction indicator lamp only goes out after 15 seconds.

If the 'General' warning light does not show:



WARNING

Faulty "General" warning light.

No indication of malfunctions.

- Check that the 'General' warning light comes on, and that it shows red and yellow. ◀
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ABS self-diagnosis

BMW Motorrad Integral ABS performs self-diagnosis to ensure its operability. Self-diagnosis starts automatically when you switch on the ignition.

Phase 1

- » Test of the diagnosis-compatible system components with the vehicle at a standstill.



flashes.

Phase 2

- » Test of the wheel-speed sensors as the vehicle pulls away from rest.



flashes.

ABS self-diagnosis completed

- » The ABS telltale and warning light goes out.



ABS self-diagnosis not completed

The ABS function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed for the wheel speed sensors to be checked: 5 km/h)

If an indicator showing an ABS fault appears when ABS self-diagnosis completes:

- You can continue to ride. Bear in mind that neither the ABS function nor the integral braking function is available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ASC self-diagnosis

BMW Motorrad ASC performs self-diagnosis to ensure its operability. Self-diagnosis is performed automatically when you switch on the ignition.

Phase 1

» Test of the diagnosable system components with the vehicle at a standstill.



slow-flashes.

Phase 2

» Test of the diagnosis-compatible system components while the motorcycle is on the move.



slow-flashes.

ASC self-diagnosis completed

» The ASC indicator and warning light goes out.

- Check all the indicator and warning lights.



ASC self-diagnosis not completed

The ASC function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed for the wheel sensors to be checked: min 5 km/h)

If an indicator showing an ASC fault appears when ASC self-diagnosis completes:

- You can continue to ride. Bear in mind that the ASC function is not available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Running in Engine

- Until the first running-in check, vary the throttle opening and engine-speed range frequently; avoid riding at constant engine rpm for prolonged periods.
- Try to do most of your riding during this initial period on twisting, fairly hilly roads, avoiding high-speed main roads and highways if possible.
- Comply with the rpm limits for running in.



Running-in speeds

<5000 min⁻¹ (Odometer reading 0...1000 km)

No full throttle (Odometer reading 0...1000 km)



Running-in check

500...1200 km

Brake pads

New brake pads have to bed down before they can achieve their optimum friction levels. You can compensate for this initial reduction in braking efficiency by exerting greater pressure on the levers.



WARNING

New brake pads

Longer stopping distance, risk of accident

- Apply the brakes in good time. ◀

Tyres

New tyres have a smooth surface. This must be roughened by riding in a restrained manner at various heel angles until the tyres are run in. This running in procedure is essential if the tyres are to achieve maximum grip.



WARNING

New tyres losing grip on wet roads and at extreme bank angles

Risk of accident

- Ride carefully and avoid extremely sharp inclines. ◀

Shifting gear

– with Pro shift assistant^{OE}

Shift assistant Pro Requirement

The shift assistant assists upshifts and downshifts without the rider having to pull the clutch or

close the throttle. This is not an automatic-shift system. The rider is the most important part of the system and decides when to shift gears.




NOTICE

See the section entitled "Engineering details" for more information on the Pro shift assistant. ◀



NOTICE

Whenever the Pro shift assistant shifts gears, cruise control is automatically disengaged for safety reasons. ◀



- You select the gear in the usual way by means of the foot-operated shift lever.
- » Sensor **1** on the selector shaft registers the shift request and triggers shift assistance.
- » When riding at a steady speed in a low gear at high engine rpm, an attempt to shift gear without pulling the clutch can cause a severe load-change reaction. BMW Motorrad recommends disengaging the clutch for shifts in these circumstances. It is advisable to avoid using the shift assistant at engine speeds close to the

limits at which the governor cuts in to limit engine rpm.

- » Shift assistance is not available in the following situations:
 - With clutch lever pulled.
 - Gearshift lever not in initial setting.
 - Upshifts with a closed throttle valve (coasting overrun) and when braking.
- After a gearshift, the shift lever has to be fully released before another gearshift with the shift assistant can take place.

Brakes

How can stopping distance be minimised?

Each time the brakes are applied, a load distribution shift takes place with the load shifting forward from the rear to the front wheel. The sharper the motorcycle decelerates, the more load is shifted to the front wheel. The

higher the wheel load, the more braking force can be transmitted without the wheel locking. To optimise stopping distance, apply the front brakes rapidly and keep on increasing the force you apply to the brake lever. This makes the best possible use of the dynamic increase in load at the front wheel. Remember to pull the clutch at the same time. In the extreme braking situations that are trained so frequently, braking force is applied as rapidly as possible and with the rider's full force applied to the brake levers; under these circumstances, the dynamic shift in load distribution cannot keep pace with the increase in deceleration and the tyres cannot transmit the full braking force to the surface of the road.

BMW Motorrad Integral ABS prevents the front wheel from locking up.

Hazard braking

– with ABS Pro^{OE}

If you brake sharply from a speed in excess of 50 km/h, the brake light flashes rapidly as an additional warning for road users behind you.

The hazard warning lights system switches on if you brake to below 15 km/h in this process. The hazard warning lights system automatically switches off from a speed of 20 km/h.

Descending mountain passes

WARNING

Braking only with the rear brake on mountain descents

Brake fade, destruction of the brakes due to overheating

- Use both front and rear brakes, and make use of the engine's braking effect as well. ◀

Wet and dirty brakes

Wetness and dirt on the brake discs and the brake pads diminish braking efficiency.

Delayed braking action or poor braking efficiency must be reckoned with in the following situations:

- Riding in the rain or through puddles of water.
- After the vehicle has been washed.
- Riding on salted or gritted roads.
- After work has been carried on the brakes, due to traces of oil or grease.
- Riding on dirt-covered surfaces or off-road.

WARNING

Wetness and dirt result in diminished braking efficiency

Risk of accident

- Apply the brakes lightly while riding to remove wetness and dirt, or dismount and clean the brakes.
- Think ahead and brake in good time until full braking efficiency is restored. ◀

ABS Pro

– with ABS Pro^{OE}

Physical limits applicable to motorcycling

WARNING

Braking when cornering

Risk of crash despite ABS Pro

- Invariably, it remains the rider's responsibility to adapt riding style to riding conditions.
- Do not take risks that would negate the additional safety offered by this system. ◀

ABS Pro is available in all riding modes.

Possibility of a fall not precluded

Although ABS Pro provides the rider with valuable assistance and constitutes a huge advance in safety for braking with the motorcycle banked for cornering, it cannot under any circumstances be considered as redefining the physical limits that apply to motorcycling. It is still possible for these limits to be overshoot due to misjudgement or rider error. In extreme cases this can result in a crash.

Use on public roads

ABS Pro helps make the motorcycle even safer for riding on public roads. When the brakes are applied because of an unforeseen hazard when the motorcycle is banked for cornering, within the physical limits that apply to motorcycling the system

prevents the wheels from locking and skidding away.

NOTICE

ABS Pro was not developed to enhance individual braking performance with the motorcycle banked into corners in situations approaching the limits of performance.◀

Parking your motorcycle

Side stand

- Switch off the engine.

ATTENTION

Poor ground underneath the stand

Risk of damage to parts if vehicle topples

- Always check that the ground under the stand is level and firm.◀

ATTENTION

Additional weight placing strain on the side stand

Risk of damage to parts if vehicle topples

- Do not sit or lean on the vehicle while it is propped on the side stand.◀
- Extend the side stand and prop the motorcycle on the stand.
- Turn the handlebars all the way to left.
- On a gradient, the motorcycle should always face uphill; select 1st gear.

Centre stand

- Switch off the engine.

ATTENTION

Poor ground underneath the stand

Risk of damage to parts if vehicle topples

- Always check that the ground under the stand is level and firm. ◀



ATTENTION

Centre stand folds in due to sharp movements

Risk of damage to parts if vehicle topples

- Do not lean or sit on the vehicle with the centre stand extended. ◀
- Extend the centre stand and lift the motorcycle onto the stand.
- On a gradient, the motorcycle should always face uphill; select 1st gear.

Refuelling

Fuel grade

Requirement

For optimum fuel consumption, fuel should be sulphur-free or

with the lowest sulphur content possible.



ATTENTION

Engine operation with leaded fuel

Damage to catalytic converter

- Do not attempt to run the vehicle on leaded fuel or fuel with metallic additives (e.g. manganese or iron). ◀
- You can run the engine on fuel with a maximum ethanol content of 10%, i.e. E10.



Recommended fuel grade

Super unleaded (max. 10% ethanol, E10)
95 ROZ/RON
89 AKI

Refuelling



WARNING

Fuel is highly flammable

Risk of fire and explosion

- Do not smoke. Never bring a naked flame near the fuel tank. ◀



WARNING

Escape of fuel due to heat-induced expansion if fuel tank is overfilled

Risk of falling

- Do not overfill the fuel tank. ◀




ATTENTION

Wetting of plastic surfaces by fuel

Damage to the surfaces (surfaces become unsightly or dull)

- Clean plastic surfaces immediately after contact with fuel. ◀

- Make sure the ground is level and firm and place the motorcycle on its centre stand.



- Open the protective cap **2**.
- Use ignition key **1** to unlock fuel filler cap by turning it clockwise, and flip the cap open.



- Do not fill the tank past the bottom edge of the filler neck.

NOTICE

When refuelling after running on reserve, make sure that you top up the tank to a level above reserve, as otherwise the new level will not be registered and the fuel warning light indicating that the level is down to reserve will not be switched off. ◀

NOTICE

The "usable fuel capacity" specified in the technical data is the

quantity that the fuel tank could hold if refilled after it had been run dry and the engine had cut out due to a lack of fuel. ◀

 Usable fuel capacity

approx. 25 l

 Reserve fuel

approx. 4 l

- Press the fuel tank cap down firmly to close.
- Remove the ignition key and close the protective cap.

Refuelling

– with Keyless Ride^{OE}

Requirement

The steering lock is disengaged.

WARNING

Fuel is highly flammable

Risk of fire and explosion

- Do not smoke. Never bring a naked flame near the fuel tank. ◀

WARNING

Escape of fuel due to heat-induced expansion if fuel tank is overfilled

Risk of falling

- Do not overfill the fuel tank. ◀

ATTENTION

Wetting of plastic surfaces by fuel

Damage to the surfaces (surfaces become unsightly or dull)

- Clean plastic surfaces immediately after contact with fuel. ◀

- Make sure the ground is level and firm and place the motorcycle on its centre stand.
- with Keyless Ride^{OE}
- Switching off ignition (▶▶ 47).

NOTICE

The fuel filler cap can be opened within the defined waiting time after the ignition has been switched off, without the radio-operated key being within range. ◀



Waiting time for opening fuel filler cap

2 min


- » There are **two variant ways** of opening the fuel filler cap:
 - Within the after-running period.
 - After the after-running period has expired.

Version 1

- with Keyless Ride^{OE}

Requirement

Within the waiting time



- Pull up tab **1** of the fuel filler cap slowly.
- » Fuel filler cap unlocks.
- Fully open the fuel filler cap.

Version 2

- with Keyless Ride^{OE}

Requirement

After the waiting time has expired

- Bring the radio-operated key into range.
- Slowly pull tab **1** up.
 - » The telltale light for the radio-operated key flashes while the search for the radio-operated key is in progress.
- Again slowly pull up tab **1** of the fuel filler cap.
 - » Fuel filler cap unlocks.
- Fully open the fuel filler cap.



- Refuel with fuel of the grade stated above; do not fill the tank past the bottom edge of the filler neck.

NOTICE

When refuelling after running on reserve, make sure that you top up the tank to a level above reserve, as otherwise the new level will not be registered and the fuel warning light indicating that the level is down to reserve will not be switched off. ◀

NOTICE

The "usable fuel capacity" specified in the technical data is the quantity that the fuel tank could hold if refilled after it had been run dry and the engine had cut out due to a lack of fuel. ◀

 Usable fuel capacity

approx. 25 l

 Reserve fuel

approx. 4 l

- Press down firmly on the filler cap of the fuel tank.
 - » The fuel filler cap engages with an audible click.
 - » The fuel filler cap locks automatically when the waiting time expires.
 - » The engaged fuel filler cap locks immediately when you secure the steering lock or switch on the ignition.

Securing motorcycle for transportation

- Make sure that all components that might come into contact with straps used to secure the motorcycle are adequately protected against scratching. Use

adhesive tape or soft cloths, for example, for this purpose.



ATTENTION

Vehicle topples to side when being lifted on to stand

Risk of damage to parts if vehicle topples

- Secure the vehicle to prevent it toppling, preferably with the assistance of a second person.◀
- Push the motorcycle onto the transportation flat and hold it in position: do not place it on the side stand or centre stand.




ATTENTION

Trapping of components

Component damage

- Do not trap components such as brake lines or cable legs.◀
- Pass the straps on left and right through the fork bridge and strap the motorcycle down.



- Secure the tensioning straps at the rear on both sides to the frame for the rear footrest and tighten the straps.
- Tension all the straps uniformly to hold the vehicle securely.

Engineering details

General instructions.....	108
Anti-lock brake system (ABS)	108
Automatic Stability Control (ASC)	111
Electronic Suspension Adjustment (ESA)	113
Riding mode	113
Tyre pressure monitoring (RDC)	115
Shift assistant.....	116
drive-off assistant	118

General instructions

To find out more about engineering go to:

bmw-motorrad.com/technology

Anti-lock brake system (ABS)

Partially integral brakes

Your motorcycle is equipped with partially integral brakes. Both front and rear brakes are applied when you pull the handbrake lever. The footbrake lever acts only on the rear brake.

When actively intervening in the braking process, BMW Motorrad Integral ABS adapts braking-force distribution between front and rear brakes to suit the load on the motorcycle ABS.



ATTENTION

Attempted burn-out despite Integral braking function

Damage to rear brake and clutch

- Do not burn out tyres.◀

How does Integral ABS work?

The amount of braking force that can be transferred to the road depends on factors that include the coefficient of friction of the road surface. Loose stones, ice and snow or a wet road all have much lower coefficients of friction than a clean and dry asphalt surface. The lower the coefficient of friction, the longer the braking distance.

If the rider increases braking pressure to the extent that braking force exceeds the maximum transferable limit, the wheels start to lock and the vehicle loses its directional stability; a fall is im-

minent. Before this situation can occur, ABS intervenes and adapts braking pressure to the maximum transferable braking force. The wheels continue to turn and the driving stability is retained irrespective of the road condition.

What are the effects of surface irregularities?

Humps and surface irregularities can cause the wheels to lose contact temporarily with the road surface; if this happens the braking force that can be transmitted to the road can drop to zero. If the brakes are applied under these circumstances the ABS has to reduce braking force to ensure that directional stability is maintained when the wheels regain contact with the road surface. At this instant the BMW Motorrad Integral ABS must assume an extremely low

coefficient of friction, so that the wheels will continue to rotate under all imaginable circumstances, because this is the precondition for ensuring directional stability. As soon as it registers the actual circumstances, the system reacts instantly and adjusts braking force accordingly to achieve optimum braking.

What feedback does the rider receive from the Integral ABS?

If the ABS has to reduce braking force on account of the circumstances described above, vibration is perceptible through the handbrake lever.

When the handbrake lever is pulled, brake pressure is also built up at the rear wheel by the integral function. If the brake pedal is depressed after the handbrake lever is pulled, the brake pressure built up

beforehand is perceptible as counter-pressure sooner than is the case when the brake pedal is depressed either before or at the same time as the brake lever is pulled.

Rear wheel lift

Under very severe and sudden deceleration, however, under certain circumstances it is possible that the BMW Motorrad Integral ABS will be unable to prevent the rear wheel from lifting clear of the ground. If this happens the outcome can be a highsiding situation in which the motorcycle can flip over.



WARNING

Rear wheel lift due to severe braking

Risk of falling

- When you brake sharply, bear in mind that ABS control cannot always be relied on to pre-

vent the rear wheel from lifting clear of the ground.◀

What is the design baseline for Integral ABS?

Within the limits imposed by physics, the BMW Motorrad Integral ABS ensures directional stability on any surface. The system is not optimised for special requirements that apply under extreme competitive situations off-road or on the track. The driving behaviour should be adapted to actual driving skills and the road conditions.

Special situations

The speeds of the front and rear wheels are compared as one means of detecting a wheel's incipient tendency to lock. If the system registers implausible values for a lengthy period the ABS function is deactivated for safety reasons and an ABS

fault message is issued. Self-diagnosis has to complete before fault messages can be issued.

In addition to problems with the BMW Motorrad ABS, exceptional riding conditions can also cause a fault message to be issued:

- Heating up with the motorcycle on the centre stand or an auxiliary stand, engine idling or with a gear engaged.
- Rear wheel locked by the engine brake for a lengthy period, for example while descending on a loose or slippery surface.

If a fault message is issued on account of exceptional riding conditions, you can reactivate the ABS function by switching the ignition off and on again.

What significance devolves on regular maintenance?



WARNING

Brake system not regularly serviced.

Risk of accident

- In order to ensure that the ABS is always maintained in optimum condition, it is essential for you to comply strictly with the specified inspection intervals. ◀

Reserves for safety

The potentially shorter braking distances which BMW Motorrad Integral ABS permits must not be used as an excuse for careless riding. ABS is primarily a means of ensuring a safety margin in genuine emergencies.



WARNING

Braking when cornering

Risk of accident despite ABS

- Invariably, the rider bears responsibility for assessing road and traffic conditions and adopting his or her style of riding accordingly.
- Do not take risks that would negate the additional margin of safety offered by this system. ◀

Evolution of ABS to ABS Pro

– with ABS Pro^{OE}

Until now, the BMW Motorrad ABS helped ensure a very high degree of safety for braking with the motorcycle upright and travelling in a straight line. Now ABS Pro offers enhanced safety for braking in corners as well. ABS Pro prevents the wheels from locking even under

sharp braking. ABS Pro reduces abrupt changes in steering force, particularly in panic-braking situations, counteracting the vehicle's otherwise natural but undesirable tendency to straighten up.

ABS intervention

Technically speaking, depending on the riding situation ABS Pro adapts ABS intervention to the motorcycle's bank angle. Signals for rate of roll and rate of yaw and lateral acceleration are used to calculate bank angle.

As the motorcycle is heeled over more and more as it banks into a corner, an increasingly strict limit is imposed on the brake-pressure gradient for the start of brake application. This slows the build-up of brake pressure to a corresponding degree. Additionally, pressure modulation is more

uniform across the range of ABS intervention.

Advantages for the rider

The advantages of ABS Pro for the rider are sensitive response and high braking and directional stability combined with best-case deceleration of the motorcycle, even when cornering.

Automatic Stability Control (ASC)

How does ASC work?

The BMW Motorrad ASC system compares the speed of rotation of the front wheel and the rear wheel. The differential is used to compute slip as a measure of the reserves of stability available at the rear wheel. If slip exceeds a certain limit, the engine control intervenes and adapts the engine torque accordingly.

What is the design baseline for ASC?

BMW Motorrad ASC has been designed as an assistance system for riders to use on public roads. The extent to which the rider affects ASC control can be considerable (weight shifts when cornering, items of luggage loose on the motorcycle), especially when the style of riding takes rider and machine close to the limits imposed by physics.

The system is not optimised for special requirements that apply under extreme competitive situations off-road or on the track. The BMW Motorrad ASC can be deactivated in these cases.

**WARNING****Risky riding**

Risk of accident despite ASC

- Invariably, the rider bears responsibility for assessing road and traffic conditions and adopting his or her style of riding accordingly.
- Do not take risks that would negate the additional safety offered by this system. ◀

Special situations

In accordance with the laws of physics, the ability to accelerate is restricted more and more as the angle of heel increases. Consequently, there can be a perceptible lag in acceleration out of very tight bends.

The speeds of the front and rear wheels are compared as one means of detecting the rear wheel's incipient tendency to

spin or slip sideways. If the system registers implausible values for a lengthy period the ASC function is deactivated for safety reasons and an ASC fault message is issued. Self-diagnosis has to complete before fault messages can be issued.

The following exceptional riding conditions can lead to an automatic shutdown of the BMW Motorrad ASC:

- Riding for a lengthy period with the front wheel lifted off the ground (Wheelie) with ASC deactivated.
- Rear wheel rotating with the vehicle held stationary by applying the front brake (Burn Out).
- Heating up with the motorcycle on the centre stand or an auxiliary stand, engine idling or with a gear engaged.

Accelerating the motorcycle to a defined minimum speed after switching the ignition off and then on again reactivates the ASC.



Minimum speed for activation of ASC

min 10 km/h

If the front wheel lifts clear of the ground under severe acceleration, the ASC reduces engine torque until the front wheel regains contact with the ground. Under these circumstances, BMW Motorrad recommends rolling the throttle slightly closed so as to restore stability with the least possible delay.

When riding on a slippery surface, never snap the throttle twistgrip fully closed without pulling the clutch at the same time. Engine braking torque can

cause the rear wheel to lock, with a corresponding loss of stability. The BMW Motorrad ASC is unable to control a situation of this nature.

Electronic Suspension Adjustment (ESA)

– with Dynamic ESA^{OE}

Dynamic ESA range of adjustment

Dynamic ESA enables you to adjust your motorcycle's suspension to suit the load and the road conditions.

Via ride height sensors, Dynamic ESA detects the movements in the chassis and suspension and responds to the same by adjusting the damper valves. The chassis and suspension will thus be adapted to the characteristics of the terrain.

You can set the damping to a harder (HARD) or softer (SOFT)

setting than the basic setting (NORMAL).

ESA calibrates itself at regular intervals when stationary with the engine running to ensure the correct operating principle of the system. During this calibration, chassis and suspension adjustment is not possible.

– with Pro riding modes^{OE}

The suspension setting depends on the riding mode selected. The damping defined by the riding mode can be changed by the rider.

Riding mode

Riding mode

Riding mode selection

Three riding modes enable the motorcycle's characteristics to adapt to the prevailing weather conditions, the road and traffic, and the rider's style of riding:

- RAIN
- ROAD

- with Pro riding modes^{OE}
- DYNAMIC

Each of these modes produces perceptible differences in the way the motorcycle behaves. ASC can be switched off in each mode; the explanations below invariably refer to conditions with the system switched ON. The mode last selected is automatically reactivated after the ignition has been switched off and then on again.

Broadly speaking: The more dynamic the selected mode, the more ASC assistance is reduced. Consequently, you must always bear the following in mind with regard to your selection of a ride mode: the more dynamic the setting, the greater the challenge to your riding skill.

Throttle response:

- in the RAIN mode: Restrained
- in the ROAD mode: Direct
- with Pro riding modes^{OE}
- in the DYNAMIC mode: Dynamic

RAIN mode

The ASC system intervenes early enough to prevent the rear wheel from spinning. On road surfaces with high to medium grip (dry and wet asphalt to dry cobblestones) the motorcycle remains very stable; movements of the tail are clearly perceptible only on slippery road surfaces (wet bitumen or wet cobblestones).

ROAD mode

ASC system intervention is later than in RAIN mode. On road surfaces with high to medium grip (dry and wet asphalt to dry cobblestones) the motorcycle re-

mains stable. Slight rear-wheel drift is perceptible. Movements of the tail are clearly perceptible on slippery road surfaces (wet bitumen or wet cobblestones).

- with Pro riding modes^{OE}

DYNAMIC mode

The DYNAMIC mode is the sportiest mode.

ASC system intervention is even later, which means that even on dry asphalt drifting is possible under sharp acceleration when cornering.

ABS

- The rear wheel lift assistant is active in all modes.
- ABS has been calibrated for on-road operation.

- with ABS Pro^{OE}
 - In RAIN and ROAD driving modes ABS Pro is fully available. The tendency of the motorcycle to straighten up when the brakes are applied with the machine banked for cornering is reduced to a minimum.
 - In DYNAMIC driving mode ABS Pro is available in conditions with a good coefficient of friction only. Support is reduced compared with ROAD driving mode and instead, the vehicle is configured for maximum braking effect.
 - with Dynamic ESA^{OE}
- ### **Dynamic ESA**
- In the RAIN, ROAD and DYNAMIC modes, the damping variants HARD, NORMAL and SOFT can be selected.

Basic setting for:

- RAIN: SOFT
- ROAD: NORMAL

- with Pro riding modes^{OE}
- DYNAMIC: HARD

Changing the riding modes

A mode change involving functions in the engine management system and the ASC system is possible only when drive torque is not applied to the rear wheel.

In order to achieve this state,

- the motorcycle must be at a standstill with the ignition switched on,

or

- the throttle twistgrip must be in the fully closed position.

Tyre pressure monitoring (RDC)

- with tyre pressure monitoring (RDC)^{OE}

Function

A sensor integrated into each tyre measures the air temperature and the air pressure inside the tyre and transmits this information to the control unit. Each sensor has a centrifugal-force tripswitch that does not enable transmission of the measured values until the motorcycle has accelerated to a defined minimum speed for the first time.



Minimum speed for transmission of the RDC measured values:

min 10 km/h

The display shows -- for each tyre until the tyre-pressure signal is received for the first time. The

sensors continue to transmit the measured-value signals for some time after the vehicle comes to a stop.



Time for transmission of measured values after vehicle comes to a stop:

min 15 min

An error message is issued if wheels without sensors are fitted to a vehicle equipped with an RDC control unit.

Tyre-pressure ranges

The RDC control unit differentiates between three tyre-pressure ranges, all of which are parameterised for the motorcycle:

- Tyre pressure within permitted tolerance.
- Tyre pressure close to limit of permitted tolerance.
- Tyre pressure outside permitted tolerance.

Temperature compensation

Tyre pressure is a temperature-sensitive variable: pressure increases as tyre-air temperature rises and decreases as tyre-air temperature drops. Tyre-air temperature depends on ambient temperature as well as on the style of riding and the duration of the ride.



The tyre-pressure readings in the multifunction display are temperature-compensated and are always referenced to the following tyre-air temperature:

20 °C

The air lines available to the public in petrol stations and motorway service areas have gauges that do not compensate for temperature; the reading shown by a gauge of this nature is the temperature-dependent tyre-

air pressure. In most instances, therefore, these gauge readings will not tally with the pressures shown by the multifunction display.

Pressure adaptation

Compare the RDC value on the multifunction display with the value in the table on the inside cover of the Rider's Manual. Then use the air line at a service station to compensate for the difference between the RDC reading and the value in the table.



Example

According to the Rider's Manual, the tyre pressure should be:

2.5 bar



Example

The multifunction display shows the following reading:

2.3 bar

So pressure is low by:

0.2 bar

The gauge on the air line shows:

2.4 bar

You must now increase tyre pressure until the value is:

2.6 bar

Shift assistant

– with Pro shift assistant^{OE}

Shift assistant Pro

Your vehicle is equipped with the shift assistant which was initially developed for racing and has been adapted for touring. It

permits upshifts and downshifts without declutching or closing the throttle in virtually all load and rpm ranges.

Advantages


- 70-80 % of all gearshifts on a trip can be done without using the clutch.
- Less relative movement between rider and passenger because the shift pauses are shorter.
- It is not necessary to close the throttle valve when shifting under acceleration.
- When braking and downshifting (throttle valve closed), engine speed is adjusted by blipping the throttle.
- Shift time is shorter than a gearshift with clutch actuation.

In order for the system to identify a request for a gearshift, the rider has to move the shift lever from its idle position in the desired direction against the force of the spring through a certain "over-travel" at ordinary speed or rapidly and keep the shift lever in this position until the gearshift is completed. It is not necessary to increase the force applied to the shift lever while shifting is in progress. Once the gearshift has completed the shift lever has to be fully released before another gearshift with the Pro shift assistant can take place. Keep the corresponding load condition (throttle grip position) constant before and during the gear shift for gear shifts using the shift assistant. A change in the position of the throttle twistgrip during a gearshift can cause the function to abort and/or lead to a missed shift. The shift assistant provides

no assistance for the gearshift if the rider declutches.

Downshifting

- Downshifting is assisted until maximum rpm for the target gear to be selected is reached. This prevents overrevving.



Upshifting

- Upshifting is assisted until idle rpm for the target gear to be selected is reached.
- This prevents the engine from dropping below idle speed.



Idle speed

1150 min⁻¹ (Engine at regular operating temperature)

drive-off assistant

– with Hill Start Control^{OE}

Hill Start Control

Hill Start Control is a pullaway assistant that operates on the partially integrated ABS system to prevent the vehicle from rolling back on a gradient without the rider having to keep pressure applied to the brake lever. When Hill Start Control is activated pressure is built up in the rear brake system to keep the machine at a standstill on a gradient. The holding pressure built up in the brake system depends on the steepness of the gradient.

Maintenance

General instructions.....	120
Standard toolkit	120
Service toolkit.....	120
Front-wheel stand	121
Engine oil	122
Brake system	123
Clutch	128
Coolant	128
Tyres	130
Rims and tyres.....	130
Silencer.....	131
Wheels	133
Light source	139
Jump-starting.....	146
Battery.....	147

Fuses	151
Diagnostic connector	153

Front-wheel stand


Installing the front-wheel stand

ATTENTION


Use of the BMW Motorrad front wheel stand without accompanying use of centre stand or auxiliary stand

Risk of damage to parts if vehicle topples


- Place the motorcycle on its centre stand or another auxiliary stand before lifting the front wheel with the BMW Motorrad front-wheel stand. ◀
- Make sure the ground is level and firm and place the motorcycle on its centre stand.
- Use basic stand with front-wheel adapter. The basic stand and its accessory parts are available from your BMW Motorrad dealer.



- Slacken securing screw **1**.
- Push the two adapters **2** apart until the front forks fit between them.
- Use locating pins **3** to set the front-wheel stand to the desired height.
- Centre the front-wheel stand relative to the front wheel and push it against the front axle.



- Align the two adapters **2** so that the front forks are securely seated.
- Tighten securing screw **1**.



ATTENTION

Centre stand retracts if motorcycle is lifted too high

Risk of damage to parts if vehicle topples

- When raising the vehicle, make sure that the centre stand remains on the ground.◀
- Apply uniform pressure to push the front-wheel stand down and raise the motorcycle.

Engine oil

Checking engine oil level

ATTENTION

Misinterpretation of oil level reading, because oil level is temperature-dependent (the higher the temperature, the higher the oil level)

Engine damage

- Check the oil level only after a lengthy ride or when the engine is at operating temperature.◀
- Switch off the engine when it is at operating temperature.
- Make sure the ground is level and firm and place the motorcycle on its centre stand.
- Wait five minutes for the oil to drain into the oil pan.



- Check the oil level in oil-level indicator **1**.



Engine oil, specified level

Between MIN and MAX marks

If the oil level is below the MIN mark:

- Topping up the engine oil (➡ 123).

If the oil level is above the MAX mark:

- Have the oil level corrected by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Topping up the engine oil

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Wipe the area around the oil filler neck clean.
- Use oil filler cap tool **1** to remove cap **2** from the oil filler neck.
- Engage oil filler cap tool **1** in cap **2** of the oil filler neck and turn the tool counter-clockwise to remove the cap.
- Checking engine oil level (➡ 122).



ATTENTION

Use of insufficient engine oil or too much engine oil

Engine damage

- Always make sure that the oil level is correct.◀
- Top up the engine oil to the specified level.



Engine oil, quantity for topping up

max 0.95 l (Difference between MIN and MAX)

- Checking engine oil level (➡ 122).
- Install cap **2** of the oil filler neck.

Brake system

Checking function of brakes

- Pull the front brake lever.
 - » The pressure point must be clearly perceptible.
- Press the footbrake lever.
 - » The pressure point must be clearly perceptible.

If pressure points are not clearly perceptible:




ATTENTION

Work on brake system not in compliance with correct procedure

Risk to operational reliability of the brake system

- Have all work on the brake system undertaken by trained and qualified specialists. ◀
- Have the brakes checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.
- Visually inspect the left and right brake pads to ascertain their thickness. Viewing direction: between wheel and front suspension toward brake pads **1**.



Brake-pad wear limit, front

1.0 mm (Friction pad only, without backing plate. The wear indicators (grooves) must be clearly visible.)

Checking front brake pad thickness

- Make sure the ground is level and firm and place the motorcycle on its stand.

If the wear indicating marks are no longer clearly visible:

! WARNING


Brake-pad thickness less than permissible minimum

Diminished braking effect, damage to the brakes

- In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness.◀
- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Check the rear brake pad thickness

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Visually inspect the brake pads to ascertain their thickness. Viewing direction: between spray guard and rear wheel toward brake pads **1**.



 Brake-pad wear limit, rear

1.0 mm (Friction pad only, without backing plate.)

If the wear limit has been reached:

WARNING

Brake-pad thickness less than permissible minimum

Diminished braking effect, damage to the brakes

- In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness. ◀
- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Checking brake-fluid level, front brakes

WARNING

Not enough brake fluid in brake fluid reservoir

Considerably reduced braking power due to air in the brake system

- Check the brake-fluid level at regular intervals. ◀
- Make sure the ground is level and firm and place the motorcycle on its centre stand.
- Move the handlebars to the straight-ahead position.



- Check the brake fluid level in front reservoir **1**.

NOTICE

Wear of the brake pads causes the brake fluid level in the reservoir to sink. ◀



 Brake fluid level, front

Brake fluid, DOT4

It is impermissible for the brake fluid level to drop below the MIN mark. (Brake-fluid reservoir horizontal, motorcycle upright)

If the brake fluid level drops below the permitted level:

- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Checking the brake-fluid level, rear brakes

WARNING

Not enough brake fluid in brake fluid reservoir

Considerably reduced braking power due to air in the brake system

- Check the brake-fluid level at regular intervals. ◀
- Make sure the ground is level and firm and place the motorcycle on its centre stand.



- Check the brake fluid level in rear reservoir **1**.

NOTICE

Wear of the brake pads causes the brake fluid level in the reservoir to sink. ◀



 Brake fluid level, rear

Brake fluid, DOT4

It is impermissible for the brake fluid level to drop below the MIN mark. (Brake-fluid reservoir horizontal, motorcycle upright)

If the brake fluid level drops below the permitted level:


- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Clutch

Checking clutch function

- Pull the clutch lever.
 - » The pressure point must be clearly perceptible.
- If the pressure point is not clearly perceptible:

- Have the clutch checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.



- Check the coolant level in expansion tank **1**.



Coolant, specified level

Between MIN and MAX marks on the expansion tank (Engine cold)

If the coolant drops below the permitted level:


- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Coolant


Check coolant level

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Allow the engine to cool down.

Top up coolant



- Remove screws **1**.




- Ease side panel **3** out at the front.
 - » Lugs **4** are disengaged from the grommets.


- Work side panel **1** up and clear of side trim **2** and remove, noting the lugs **arrows**.



- Open cap **1** of the coolant expansion tank and top up the coolant to the specified level.
- Check coolant level (▬▬▬ 128).
- Close the cap of the coolant expansion tank.



- Hold side panel **1** ready with the lugs in position at side trim **2**.
- Pivot side panel **3** inward.
 - » Lugs **4** are pressed into the grommets.



- Install screws 1.

Tyres

Checking tyre pressure

WARNING

Incorrect tyre pressure

Impaired handling characteristics of the motorcycle, shorter useful tyre life

- Always check that the tyre pressures are correct.◀

WARNING

Tendency of valve inserts installed vertically top open by themselves at high riding speeds.

Sudden loss of tyre pressure.

- Install valve caps fitted with rubber sealing rings and tighten firmly.◀
- Make sure the ground is level and firm and place the motorcycle on its stand.
- Check tyre pressures against the data below.



Tyre pressure, front

2.5 bar (tyre cold)



Tyre pressure, rear

2.9 bar (tyre cold)

If tyre pressure is too low:

- Correct tyre pressure.

Rims and tyres

Checking rims

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Visually inspect the rims for defects.
- Have any damaged rims inspected by a specialist workshop and replaced if necessary, preferably by an authorised BMW Motorrad dealer.

Checking tyre tread depth

WARNING

Riding with badly worn tyres

Risk of accident due to impaired handling

- If applicable, have the tyres changed in good time before they wear to the minimum tread depth permitted by law. ◀
- Make sure the ground is level and firm and place the motorcycle on its stand.
- Measure the tyre tread depth in the main tread grooves with wear marks.

NOTICE

Wear indicators are built into the main profile grooves on each tyre. The tyre is worn out when the tyre tread has worn down to the level of the marks. The locations of the marks are indicated on the edge of the tyre, e.g.

by the letters TI, TWI or by an arrow. ◀

If the tyre tread is worn to minimum:

- Replace tyre or tyres, as applicable.

Silencer


Swinging silencer out

CAUTION


Hot exhaust system

Risk of burn injury

- Do not touch a hot exhaust system. ◀
- Make sure the ground is level and firm and place the motorcycle on its centre stand.
- Allow the silencer to cool.



- Remove screws **1** with washer **2** on front screw.
- Remove silencer cover **3**.



- Slacken screw **1** of the clamp.
- Remove screw **2** and locking washer **3**.

- Turn silencer **4** **clockwise** toward the outside.

Securing silencer




ATTENTION

Tightening threaded fasteners to incorrect tightening torque

Damage, or threaded fasteners work loose

- Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀




- Turn silencer **1** counter-clockwise until it is seated against the rear footrest bracket.
- Install washer **2** and screw **3**.



Silencer to footrest bracket

19 Nm




- Push clamp **1** as far forward as possible and position it with the recess engaging the projection (**arrow**).
- Tighten the clamp.



Clamp to silencer and exhaust manifold

22 Nm



- Place silencer cover **3** in position.
- Install screws **1** with washer **2** on front screw.

Wheels

Tyre recommendation

For each size of tyre, BMW Motorrad tests and classifies as roadworthy certain makes. BMW Motorrad cannot assess the suitability or provide any guarantee of road safety for other tyres.

BMW Motorrad recommends using only tyres tested by BMW Motorrad.

Detailed information is available from your authorised BMW Motorrad dealer or in the internet at:

bmw-motorrad.com

Effect of wheel size on chassis and suspension control systems


The wheel sizes are paramount for the ABS and ASC suspension control systems. In particular, the diameter and the width of the vehicle's wheels are programmed into the control unit and are fundamental to all calculations. Any change in these influencing variables, caused for example by a switch to wheels other than those installed ex-works, can have serious effects on the performance of the control systems.

The sensor rings are essential for correct road-speed calculation, and they too must match the motorcycle's control systems and consequently cannot be changed.

If you decide that you would like to fit non-standard wheels to your motorcycle, it is very important to consult a specialist workshop beforehand, preferably an authorised BMW Motorrad dealer. In some cases, the data programmed into the control units can be changed to suit the new wheel sizes.

RDC adhesive label

- with tyre pressure monitoring (RDC)^{OE}



ATTENTION

Tyre removal not in compliance with correct procedure

Damage to RDC sensors


- Be sure to explain to the specialist workshop or authorised BMW Motorrad dealer that the wheel is fitted with an RDC sensor. ◀

If the motorcycle is equipped with RDC, each wheel rim bears an adhesive label indicating the position of the RDC sensor. When a tyre is being changed, special care must be taken not

to damage the RDC sensor. Be sure to draw the attention of the authorised BMW Motorrad dealer or specialist workshop to the fact that the wheel is fitted with an RDC sensor.

Removing front wheel

- Make sure the ground is level and firm and place the motorcycle on its centre stand.



- Disengage the ABS sensor cable from retaining clips **1** and **2**.
- Remove screw **3** and remove the ABS sensor from its bore.


- Mask off the parts of the wheel rim that could be scratched in the process of removing the brake callipers.

ATTENTION

Unwanted inward movement of the brake pads

Component damage on attempt to install the brake caliper or because brake pads have to be forced apart


- Do not operate the brakes with a brake caliper not correctly secured. ◀
- Remove securing screws **4** of the left and right brake calipers.



- Force the brake pads **1** slightly apart by rotational movement of the brake calliper **2** against brake disc **3**.
- Carefully pull the brake callipers back and out until clear of the brake discs.
- Lift the front of the motorcycle until the front wheel is clear of the ground, preferably using a BMW Motorrad front-wheel stand.
- Installing the front-wheel stand (▮▮▮ 121).




- Remove right-hand axle clamping screw **1**.




- Remove screw **1**.
- Remove left-hand axle clamping screw **2**.
- Press quick-release axle slightly toward the inside, so as to be

better able to grip it on the right-hand side.



- Withdraw quick-release axle **1**, support the front wheel when doing this.
- Set down front wheel and roll forwards out of the front suspension.



- Remove spacer bush **1** from the wheel hub.

Installing front wheel



WARNING

Use of a non-standard wheel

Malfunction as part of ABS and ASC control interventions

- See the information on the effect of wheel size on the ABS and ASC systems at the start of this chapter. ◀




ATTENTION

Tightening threaded fasteners to incorrect tightening torque

Damage, or threaded fasteners work loose

- Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀



- Slip spacing bushing **1** into the wheel hub on the left-hand side.




ATTENTION

Front wheel installed wrong way round


Risk of accident

- Note direction-of-rotation arrows on tyre or rim. ◀
- Roll the front wheel into position between the front forks.



- Lift front wheel and fit quick-release axle **1**.
- Remove front-wheel stand and firmly compress front forks several times. Do not operate front break lever.

- Installing the front-wheel stand (→ 121).



- Install screw **1** and tighten to specified torque. Counter-hold quick-release axle on the right-hand side.

 Quick-release axle in telescopic forks

30 Nm

- Tighten left-hand axle clamping screw **2** to the specified torque.

 Clamping screw for quick-release axle in telescopic fork

19 Nm




- Tighten right axle clamping screw **1** to the specified torque.

 Clamping screw for quick-release axle in telescopic fork

19 Nm

- Removing the front-wheel stand.

- Position left and right brake calipers on the brake discs.



- Install securing screws **4** on left and right and tighten to specified tightening torque.

 Brake caliper on telescopic fork

38 Nm

- Remove the adhesive tape from the wheel rim.

WARNING

Brake pads not lying against the brake disc

Risk of accident due to delayed braking effect.

- Before driving, check that the brakes respond without delay. ◀
- Operate the brake several times until the brake pads are bedded.
- Seat the ABS sensor line in retaining clips **1** and **2**.
- Insert the ABS sensor into its bore and install screw **3**.




Wheel-speed sensor to fork leg

Joining compound: Micro-encapsulated or medium-strength thread-locking compound

8 Nm

Removing rear wheel

- Silencer, swinging out (➡ 131).



- Engage first gear.
- Remove studs **1** from the rear wheel, while supporting the wheel.
- Roll the rear wheel out toward the rear.

Installing the rear wheel



WARNING

Use of a non-standard wheel

Malfunction as part of ABS and ASC control interventions

- See the information on the effect of wheel size on the ABS and ASC systems at the start of this chapter. ◀




ATTENTION

Tightening threaded fasteners to incorrect tightening torque

Damage, or threaded fasteners work loose

- Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀
- Seat the rear wheel on the rear-wheel adapter.



- Install wheel studs **1** and tighten to specified torque.

 Rear wheel to wheel flange

Tightening sequence: tighten in diagonally opposite sequence

60 Nm

- Securing silencer ( 132).

Light source

Replacing bulb for low-beam headlight

NOTICE

The positions of the plug, the spring wire retainer and the bulb might not be as illustrated below. ◀


- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.



- Remove cover **1** by turning it counter-clockwise to replace the bulb for the low-beam headlight.



- Disconnect plug **1**.




- Disengage spring clip **1** and swing it aside.
- Remove bulb **2**.
- Replace the defective bulb.

 Bulbs for the low-beam
 headlight

H7 / 12 V / 55 W

- Hold the bulb by the base only, in order to keep the glass free of foreign matter.



- Insert bulb **2**, making sure that the tab is correctly positioned.



NOTICE

The bulb might face in a direction other than that shown here. ◀

- Engage spring clip **1** in the catch.



- Connect plug **1**.



- Insert cover **1** and turn it clockwise to install.

Replacing bulb for high-beam headlight

NOTICE


The description below steps you through the procedure for replacing the left bulb. The procedure for working on the right side is the same. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.




- Remove screws **2**.

- Ease speaker cover **1** to the left to remove.



- Remove screws **1**.
- Carefully remove speaker unit **2**, noting the plug.



- Disconnect plug **1**.



- Pull the tab to remove cover **1**.



- Disconnect plug **1**.



- Release spring clip **1** at left and right and swing it open.
- Remove bulb **2**.
- Replace the defective bulb.

 Bulb for high-beam
 headlight

H1 / 12 V / 55 W

- Hold the bulb by the base only, in order to keep the glass free of foreign matter.



- Install bulb **2**, making sure that the tab is correctly positioned.



NOTICE

The bulb might face in a direction other than that shown here. ◀


- Insert spring clip **1**.




- Connect plug **1**.



- Install cover **1**.



- Connect plug **1**.



- Seat speaker unit **2** in the mount.
- Install screws **1**.



- Hold speaker cover **1** in position and install screws **2**.

Replacing bulb for parking light

NOTICE


The description below steps you through the procedure for replacing the left bulb. The procedure for working on the right side is the same. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.

- Switch off the ignition.




- Remove screws **2**.
- Ease speaker cover **1** to the left to remove.



- Remove screws **1**.


- Carefully remove speaker unit **2**, noting the plug.



- Disconnect plug **1**.



- Remove cover **1** by turning it counter-clockwise.



- Disengage socket **1** from headlight housing **2**, but do not under any circumstances pull cable **3**.



- Remove bulb **1** from the socket.

- Replace the defective bulb.



Bulb for parking light

W5W / 12 V / 5 W


- with daytime running light^{OE} or
- with Pro Headlight^{OE}

Lighting rings, integrated into headlight◀

- Use a clean, dry cloth to hold the bulb in order to keep the glass free of foreign matter.




- Insert bulb **1** into the bulb socket.




- Install bulb socket **1** in headlight housing **2**.



- Turn cover **1** clockwise to install.



- Connect plug **1**.



- Seat speaker unit **2** in the mount.
- Install screws **1**.



- Hold speaker cover **1** in position and install screws **2**.

Replacing LED rear light

The LED rear light can be replaced only as a complete unit.

- Consult a specialist workshop, preferably an authorised BMW Motorrad dealer.

Replacing LED turn indicators

- LED turn indicators can be replaced only as a complete unit. Consult a specialist workshop, preferably an authorised BMW Motorrad dealer.

Waveguide rings, replacing

- with daytime running light^{OE}
- with Pro Headlight^{OE}

- Waveguide rings are integrated into the headlight and can be replaced only together with the headlight. Consult a specialist workshop, preferably an authorised BMW Motorrad dealer.

Replacing LED auxiliary headlights

- with LED auxiliary headlights^{OA}

The LED auxiliary headlights can only be replaced as a unit; it is not possible to replace individual LEDs.

Consult a specialist workshop, preferably an authorised BMW Motorrad dealer.

Jump-starting



ATTENTION

Excessive current flowing when the motorcycle is jump-started

Wiring smoulders/ignites or damage to the on-board electronics

- If the motorcycle has to be jump-started connect the leads to the battery terminals; never attempt to jump-start the engine by connecting leads to the on-board socket.◀



ATTENTION

Contact between crocodile clips of jump leads and vehicle

Risk of short-circuit

- Use jump leads fitted with fully insulated crocodile clips at both ends.◀




ATTENTION

Jump-starting with a voltage greater than 12 V

Damage to the on-board electronics

- Make sure that the battery of the donor vehicle has a voltage rating of 12 V.◀
- Place the motorcycle on its stand on firm, even ground.
- Removing battery cover (▶▶ 149).
- When jump-starting the engine, do not disconnect the battery from the on-board electrical system.



- Remove protective cap **1**.
- Connect the red jump lead to the positive battery connection point **2** of the drained battery and the positive terminal of the donor battery.
- Then connect one end of the black jump lead to the negative terminal of the donor battery and the other end to negative terminal **3** of the discharged battery.
- Run the engine of the donor vehicle during jump-starting.
- Start the engine of the vehicle with the discharged battery in the usual way; if the en-

gine does not start, wait a few minutes before repeating the attempt in order to protect the starter motor and the donor battery.

- Allow both engines to idle for a few minutes before disconnecting the jump leads.
- Disconnect the jump lead from the negative terminals first, then disconnect the second lead from the positive terminals.



NOTICE

Do not use proprietary start-assist sprays or other products to start the engine. ◀

- Install the protective cap.
- Fitting battery cover (► 151).

Battery

Maintenance instructions

Correct upkeep, recharging and storage will prolong the life of the battery and are essential if warranty claims are to be considered.

Compliance with the points below is important in order to maximise battery life:

- Keep the surface of the battery clean and dry.
- Do not open the battery.
- Do not top up with water.
- Be sure to read and comply with the instructions for charging the battery on the following pages.
- Do not turn the battery upside down.

 **ATTENTION**
On-board electronics (e.g. clock) draining connected battery

Battery is deep-discharged; this voids the guarantee

- Connect a float charger to the battery if the motorcycle is to remain out of use for more than four weeks. ◀

 **NOTICE**

BMW Motorrad has developed a float charger specially designed for compatibility with the electronics of your motorcycle. Using this charger, you can keep the battery charged during long periods of disuse, without having to disconnect the battery from the motorcycle's on-board systems. You can obtain additional information from your authorised BMW Motorrad dealer. ◀

Charge battery when connected
 **ATTENTION**
Charging the battery that is connected to the vehicle via the battery terminals

Damage to the on-board electronics

- Disconnect the battery at the battery terminals before charging. ◀

 **ATTENTION**
Charging a fully discharged battery via the socket or the extra socket

Damage to the on-board electronics

- If a battery has discharged to the extent that it is completely flat (battery voltage less than 9 V, status-indicator lights and multifunction display remain off when the ignition is switched

on) **it has to be disconnected from the on-board circuits** and re-charged with the charger connected directly to the battery posts. ◀

 **ATTENTION**
Unsuitable chargers connected to a socket

Damage to charger and vehicle electronics

- Use suitable BMW chargers. The suitable charger is available from your authorised BMW Motorrad dealer. ◀
- Charge via the charging socket, with the battery connected to the motorcycle's on-board electrical system.

 **NOTICE**

The motorcycle's on-board electronics know when the battery is fully charged. The on-board

socket is switched off when this happens.◀

- Comply with the operating instructions of the charger.

NOTICE

If you are unable to charge the battery through the on-board socket, you may be using a charger that is not compatible with your motorcycle's electronics. If this happens, charge the battery directly at the terminals of the battery that is disconnected from the vehicle.◀

Charging battery when disconnected


- Charge the battery using a suitable charger.
- Comply with the operating instructions of the charger.
- Once the battery is fully charged, disconnect the

charger's terminal clips from the battery terminals.

NOTICE

The battery has to be recharged at regular intervals in the course of a lengthy period of disuse. See the instructions for caring for your battery. Always fully recharge the battery before restoring it to use.◀

Removing battery




- Switch off the ignition.
- Remove screws **1**.
- Remove the battery cover.

- with alarm system (DWA)^{OE}
- If applicable, switch off the anti-theft alarm (DWA).◀



- Disconnect battery negative lead **1** and disengage rubber strap **2**.




- Pull retaining plate in position **1** outwards and remove in an upward direction.
- Slightly lift the battery and ease it clear of the holder until the battery positive terminal is accessible.



- Disconnect battery negative lead **1** and remove the battery.
» The battery is removed.

Installing battery




- Secure battery positive lead **1**.




NOTICE

If the 12 V battery is not correctly installed or if the polarity of the terminals is reversed (e.g. in an attempt to jump-start the vehicle), this can cause the fuse for the alternator regulator to blow. ◀


- Push battery into the mounting.




- First push the retaining plate under the battery at position **1** and then seat it in mounts **2**.



- Secure battery negative lead **1**.
- Secure the battery with rubber strap **2**.




- Insert the battery cover into the mounting **1** and press it into the mountings **1** and **2**.



- Install screws **1**.
- Switch on the ignition.
- Adjust the time and date in the **Settings - Time and Settings - Date** menu.

Fuses

Replace fuses



- Switch off the ignition.
- Removing front seat (➡ 74).
- Disconnect plug **1**.



ATTENTION

Jumpering of blown fuses

Risk of short-circuit and fire

- Never attempt to jumper a blown fuse.
- Always replace a defective fuse with a new fuse of the same amperage. ◀

- Consult the fuse assignment diagram and replace the defective fuse.




NOTICE

If fuse defects recur frequently have the electric circuits checked by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

- Installing front seat (➡ 75).


Fuse assignment



Fuse box

15 A (Slot 1: Instrument cluster, alarm system (DWA), ignition lock, diagnostic socket, topcase light)

7.5 A (Slot 2: Multifunction switch left, tyre pressure control (RDC), audio system)



Fuse holder

50 A (Fuse 1: Voltage regulator)

Diagnostic connector

Disengaging diagnostic connector

CAUTION


Incorrect procedure followed when loosening the diagnostic connector for the on-board diagnosis

Motorcycle experiences malfunctions

- Only have the diagnostic connector loosened by a specialist workshop or other authorised persons during your next BMW Service appointment.
- Have the work performed by appropriately trained staff.
- Refer to the vehicle manufacturer specifications.◀
- Removing battery cover (▶▶ 149).



- Press the hook **1** and pull out the diagnostic connector **2** towards the top.




- Press the locks **3** on both sides.

- Loosen the diagnostic connector **2** from the bracket **4**.
» The interface to the diagnosis and information system can be connected to diagnostic connector **2**.

Securing the diagnostic connector

- Disconnect the interface for the diagnosis and information system.



- Insert the diagnostic connector **2** into the bracket **4**.
» The locks **3** engage on both sides.

- Connect the bracket **4** to the mounting **1**.



- Make sure the hook **5** engages.
- Fitting battery cover (☞ 151).

Accessories

General instructions.....	156
Power sockets	156
Cases.....	157
Topcase	159
Navigation system	162

General instructions

CAUTION

Use of other-make products

Safety risk

- BMW Motorrad cannot examine or test each product of outside origin to ensure that it can be used on or in connection with BMW vehicles without constituting a safety hazard. Country-specific official authorisation does not suffice as assurance. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW vehicles and, consequently, they are not sufficient in some circumstances.
- Use only parts and accessories approved by BMW for your vehicle. ◀

BMW has conducted extensive testing of the parts and ac-

cessory products to establish that they are safe, functional and suitable. Consequently, BMW accepts product liability. BMW accepts no liability whatsoever for parts and accessories that it has not approved.

Whenever you are planning modifications, comply with all the legal requirements. Make sure that the vehicle does not infringe the national road-vehicle construction and use regulations applicable in your country. Your BMW Motorrad dealer can offer expert advice on the choice of genuine BMW parts, accessories and other products. To find out more about accessories go to:

**[bmw-motorrad.com/
accessories](http://bmw-motorrad.com/accessories)**

Power sockets

Connection of electrical devices

- You can start using electrical devices connected to the motorcycle's sockets only when the ignition is switched on.

Cable routing

- The cables from the power sockets to the auxiliary devices must be routed in such a way that they do not impede the rider.
- The cable routing should not restrict the steering angle or obstruct handling.
- The cables must not be trapped.

Automatic shutdown

- The sockets will be automatically switched off during the start procedure.

- The power supply to the sockets is switched off a certain time after the ignition is switched off, in order to prevent overloading of the on-board electrics. Low-wattage electrical accessories might not be recognised by the vehicle's electronics. In such cases, power sockets are switched off very shortly after the ignition is turned off.

	<p>Automatic shutdown of the sockets after ignition OFF</p>
<p>max 15 min</p>	

- If the battery charge state is too low to maintain the motorcycle's start capability, the power sockets are switched off.
- The power sockets are also switched off when the maximum load capability as stated

in the technical data is exceeded.


Cases

Open cases

- with central locking system^{OE}
- If applicable, open the central locking.◁



- Turn the key to the in the case lock to the position indicated by the dot.



- Push lock barrel **1** down.
» Lever **2** pops up.
- Pull the release lever all the way up and open the lid of the case.

Closing cases



- Pull release lever **2** all the way up.
- Close the lid of the case and press it down. Check that nothing is trapped between the lid and the case.



NOTICE

The cases can also be locked by turning the lock to the LOCK position. In this case, ensure that the vehicle key is not left in the cases. ◀

- Push release lever **2** down until it engages.

- Turn the key in the case lock to the LOCK position and remove the key from the lock.

Removing cases



- Turn the key to the RELEASE position in the case lock.
 - » The handle pops out.



- Pull carry handle **3** up as far as it will go.
 - » The case is released and can be removed.

Install cases

- Pull the handle up as far as it will go.



- Seat the case in holders **4**.



- Push handle **3** down until it engages.
- Turn the key in the case lock to the LOCK position and remove the key from the lock.

Maximum payload and maximum permissible speed

Note the maximum permissible payload and the speed limit for riding with cases fitted, as stated on the label inside the case. Contact your authorised BMW Motorrad dealer if you cannot find your combination of vehicle and cases on the label. The values for the combination described here are as follows:

	Maximum permissible speed for riding with cases fitted to the motorcycle
max 180 km/h	
	Payload per case
max 10 kg	


Topcase

Opening topcase

- with topcase^{OA}
- with central locking system^{OE}
- If applicable, open the central locking.<



- Turn the key to the in the topcase lock to the position indicated by the dot.



- Push lock barrel **1** forward.
» Lever **2** pops up.
- Pull the release lever all the way up and open the lid of the topcase.

Closing topcase

– with topcase^{OA}



- Pull release lever **2** all the way up.
- Close the lid of the topcase and hold it down. Check that nothing is trapped between the lid and the case.



NOTICE

The topcase can also be locked by turning the lock to the LOCK position. In this case, ensure that the vehicle key is not left in the topcase.◀

- Push release lever **2** down until it engages.

- Turn the key in the topcase lock to the LOCK position and remove the key from the lock.

Removing the topcase

- Removing front seat (▶▶▶ 74).
- Removing rear seat (▶▶▶ 76).
– with topcase^{OA}



- Disconnect plug **1**.
- Work the plug of the topcase through to the rear.
- Open the topcase.
- If applicable, empty the topcase and lift out the bottom mat.



- Push slide latch **2** toward the outside and hold it in this position.
- Turn rotary latch **3** in the direction indicated by the RELEASE arrow.
- » Release warning **4** is visible.
- Close the topcase.




- Lift the topcase at the rear and remove it from the luggage carrier.<
- Installing the rear seat (➡ 77).
- Installing front seat (➡ 75).

Installing topcase

- Removing front seat (➡ 74).
- Removing rear seat (➡ 76).
– with topcase^{OA}
- If applicable, empty the topcase and lift out the bottom mat.



- Set the topcase on the luggage carrier.
- Opening topcase (➡ 159).




- Turn rotary latch **3** as far as it will go in the direction indicated by the LOCK arrow

while pressing down on the back edge of the topcase.


» Release warning **4** is no longer visible.

If the release warning is still visible the topcase is not correctly secured.

- Make sure that the topcase is correctly seated on the luggage carrier.



- Route the connecting cable forward in cable guide **5**.



- Work the cable into position at positions **6**.
- Connect plug **1**.
- Install the rear seat (➡ 77).
- Installing front seat (➡ 75).

Maximum payload and maximum permissible speed

Note the maximum permissible payload and the speed limit for riding with topcase fitted, as stated on the label inside the topcase.

Contact your authorised BMW Motorrad dealer if you cannot

find your combination of vehicle and topcase on the label.

The values for the combination described here are as follows:

	Maximum permissible speed for riding with Vario topcase fitted to the motorcycle
max 180 km/h	
	Payload of Vario topcase
max 5 kg	

Navigation system Securing navigation device

- with navigation system^{OA}
- with preparation for navigation system^{OE}



ATTENTION

Dust and dirt on the Mount Cradle contacts

Damaged contacts

- Always reinstall the cover as soon as you finish your ride.◀



NOTICE

The Mount Cradle lock system is not designed to protect against theft.

- Always remove the navigation system and stow it away safely as soon as you finish your ride.◀



- Operate latch **1** and remove cover **2**.



- First seat navigation device **1** in the mount and then pivot it to the rear **2**.

- Press down on the top edge of the navigation device until it engages.




- Check that the navigation device is secure in the cradle. Latch **1** must be fully engaged. The latching mechanism must lie flat and be out of sight.

Removing navigation device

- with navigation system^{OA}
- with preparation for navigation system^{OE}




- Operate latch **1** and remove navigation device **2**.



- Install cover **2**.
- Check that the cover is secure in the cradle. Top retaining cap **1** must be fully engaged.

Operating navigation system

- with preparation for navigation system^{OE}
- If applicable, switch on the ignition.
- Call up the **Navigation** menu.



The options for using the navigation system appear on the display.

- **Page**: switches between the main menu, map and on-board computer views.

- **Zoom +**: carries out functions labelled with a + in the navigation system. In the map view, for instance, the view zooms in on the map detail.
- **Zoom -**: carries out functions labelled with a - in the navigation system. In the map view, for instance, the view zooms out from the map detail.
- **Speak**: repeats the last navigation command. The announcement is spoken again even if automatic spoken announcement have been switched off in the settings of the navigation system.
- **Mute**: switches automatic voice output off and on.
- **Display Off**: switches the navigation system display on and off.
- Select the function you want and implement the function by pushing the Multi-Controller to the right.

Special functions

- with preparation for navigation system^{OE}

Integration of the BMW Motorrad Navigator V can result in deviations from the descriptions in the operating instructions for the Navigator.

Reserve fuel level warning

The settings for the fuel gauge enable you to define a distance that is covered per full tank of fuel. The motorcycle sends the figure for residual range possible with the fuel remaining in the fuel tank to the Navigator, so it is no longer necessary to enter this value.

Time and date

The Navigator sends time and date to the motorcycle. The transfer of these data into the instrument cluster must be activ-

ated in the SETUP menu of the instrument cluster.

Security settings

The BMW Motorrad Navigator V can be secured against unauthorised use with a four-digit PIN (Garmin Lock). If this function is activated, while the Navigator is cradled on the motorcycle and the ignition is switched on you are prompted to add the motorcycle to the list of secured vehicles. If you answer "Yes" at this prompt the Navigator saves the VIN of this vehicle in its internal memory.

A maximum of five VINs can be saved in this way.

Subsequently, the PIN does not have to be entered when the Navigator is switched on by ignition ON while cradled in any of these vehicles.

If the Navigator is removed from the vehicle while switched on, a

security prompt asking for the PIN to be entered is issued.

Care

Care products	168
Washing the vehicle	168
Cleaning easily damaged components.....	169
Paint care	170
Protective wax coating	170
Laying up the motorcycle	170
Restoring motorcycle to use	170

Care products

BMW Motorrad recommends that you use the cleaning and care products you can obtain from your authorised BMW Motorrad dealer.

The substances in BMW CareProducts have been tested in laboratories and in practice; they provide optimised care and protection for the materials used in your vehicle.



ATTENTION

Use of unsuitable cleaning and care products

Damage to vehicle parts

- Do not use solvents such as cellulose thinners, cold cleaners, fuel or the like, and do not use cleaning products that contain alcohol. ◀

Washing the vehicle

BMW Motorrad recommends that you use BMW insect remover to soften and wash off insects and stubborn dirt on painted parts prior to washing the vehicle.

To prevent stains, do not wash the vehicle immediately after it has been exposed to strong sunlight and do not wash it in the sun.

Make sure that the vehicle is washed frequently, especially during the winter months.

To remove road salt, clean the motorcycle with cold water immediately after every trip.



WARNING

Wet brake discs and brake pads after vehicle wash, after riding through water and in rainy conditions

Diminished braking effect, risk of accident

- Apply the brakes in good time to allow the friction and heat to dry the brake discs and brake pads. ◀



ATTENTION

Effect of road salt intensified by warm water

Corrosion

- Use only cold water to wash off road salt. ◀



ATTENTION

Damage due to high water pressure from high pressure cleaners or steam cleaners

Corrosion or short-circuit, damage to seals, to the hydraulic brake system, to the electrics and the seat

- Exercise restraint when using a steam jet or high-pressure cleaning equipment.◀

Cleaning easily damaged components

Plastics



ATTENTION

Use of unsuitable cleaning agents

Damage to plastic surfaces

- Do not use cleaning agents that contain alcohol, solvents or abrasives.
- Do not use insect-remover pads or cleaning pads with hard, scouring surfaces.◀

Body panels

Clean the trim panels with water and BMW plastic care emulsion.

Windscreens and lenses made of plastic

Clean off dirt and insects with a soft sponge and plenty of water.



NOTICE

Soften stubborn dirt and insects by covering the affected areas with a wet cloth.◀



Clean with water and sponge only.



Do not use any chemical cleaning agents.

Chrome

Use plenty of water and BMW shampoo to clean chrome, particularly if it has been exposed to road salt. Use chrome polish for additional treatment.

Radiator

Clean the radiator regularly to prevent overheating of the engine due to inadequate cooling. For example, use a garden hose with low water pressure.



ATTENTION

Bending of radiator fins

Damage to radiator fins

- Take care not to bend the radiator fins when cleaning.◀

Rubber components

Treat rubber components with water or BMW rubber-care products.



ATTENTION

Application of silicone sprays to rubber seals

Damage to the rubber seals

- Do not use silicone sprays or care products that contain silicon.◀

Paint care

Washing the vehicle regularly will help counteract the long-term effects of substances that damage the paint, especially if your vehicle is ridden in areas with high air pollution or natural sources of dirt, for example tree resin or pollen.

Remove particularly aggressive substances immediately, however, as otherwise the paint can be affected or become discoloured. Substances of this nature include spilt fuel, oil, grease, brake fluid and bird droppings. We recommend BMW vehicle polish or BMW paint cleaner for this purpose.

Marks on the paintwork are particularly easy to see after the vehicle has been washed. Remove stains of this kind immediately, using cleaning-grade benzene or petroleum spirit on a clean cloth or ball of cotton wool.

BMW Motorrad recommends using BMW tar remover for removing specks of tar. Remember to wax the parts treated in this way.

Protective wax coating

If water is no longer forming beads on the paint surface, it must be waxed.

BMW Motorrad recommends applying only BMW car wax or products containing carnauba wax or synthetic wax.

Laying up the motorcycle

- Clean the motorcycle.
- Fill the motorcycle's fuel tank with fuel.
- Removing battery (🔗 149).
- Spray the brake and clutch lever pivots and the main and side stand pivots with a suitable lubricant.
- Coat bright metal and chrome-plated parts with an acid-free grease (e.g. Vaseline).
- Stand the motorcycle in a dry room in such a way that there is no load on either wheel (preferably using the front-wheel and rear-wheel stands from BMW Motorrad).

Restoring motorcycle to use

- Remove the protective wax coating.
- Clean the motorcycle.
- Installing battery (🔗 150).
- Comply with checklist (🔗 94).

Technical data

Troubleshooting chart	172
Threaded fasteners	173
Fuel.....	175
Engine oil	175
Engine	176
Clutch	177
Transmission	177
Final drive.....	178
Frame	178
Chassis and suspension	179
Brakes	180
Wheels and tyres	181
Electrical system.....	183
Anti-theft alarm	184
Dimensions	185

Weights.....	186
Riding specifications	186

Troubleshooting chart

The engine does not start.

Possible cause	Rectification
Side stand extended and gear engaged	Retract the side stand.
Gear engaged and clutch not disengaged	Select neutral or pull the clutch lever.
No fuel in tank	Refuelling (▮▮▮▶ 102).
Battery flat	Charge battery when connected (▮▮▮▶ 148).
Overheating protection for starter motor has been activated. Starter motor can only be operated for a limited period of time.	Allow the starter motor to cool down for approx. 1 minute before using it again.

Threaded fasteners

Front wheel	Value	Valid
Brake caliper on telescopic fork		
M10 x 65	38 Nm	
Clamping screw for quick-release axle in telescopic fork		
M8 x 35	19 Nm	
Wheel-speed sensor to fork leg		
M6 x 16 Micro-encapsulated or medium-strength thread-locking compound	8 Nm	
Quick-release axle in telescopic forks		
M12 x 20	30 Nm	
Rear wheel	Value	Valid
Rear wheel to wheel flange		
M10 x 1.25 x 40	Tighten in diagonally opposite sequence	
	60 Nm	

Exhaust system	Value	Valid
Silencer to footrest bracket		
M8 x 35	19 Nm	
Clamp to silencer and exhaust manifold		
	22 Nm	
Mirror arm	Value	Valid
Mirror to holder		
M6 x 50	8 Nm	

Fuel

Recommended fuel grade	Super unleaded (max. 10 % ethanol, E10) 95 ROZ/RON 89 AKI
Usable fuel capacity	approx. 25 l
Reserve fuel	approx. 4 l
Exhaust emissions standard	EU 4

Engine oil

Engine oil, capacity	max 4 l, with filter change
Specification	SAE 5W-40, API SL / JASO MA2, Additives (e.g. molybdenum-based) are not permissible because they can attack coated components of the engine, BMW Motorrad recommends BMW Motorrad ADVANTEC Ultimate oil.
Engine oil, quantity for topping up	max 0.95 l, Difference between MIN and MAX

BMW recommends **ADVANTEC**
ORIGINAL BMW ENGINE OIL

Engine

Location of engine number	Crankcase, bottom right, below starter motor
Engine type	122EN
Engine design	Air-/liquid-cooled two-cylinder four-stroke opposed-twin engine with two overhead spur-gear-driven camshafts and one balancing shaft
Displacement	1170 cm ³
Cylinder bore	101 mm
Piston stroke	73 mm
Compression ratio	12.5:1
Nominal output	92 kW, at engine speed: 7750 min ⁻¹
– with power reduction ^{OE}	79 kW, at engine speed: 7750 min ⁻¹
Torque	125 Nm, at engine speed: 6500 min ⁻¹
– with power reduction ^{OE}	122 Nm, at engine speed: 5250 min ⁻¹
Maximum engine speed	max 9000 min ⁻¹
Idle speed	1150 min ⁻¹ , Engine at regular operating temperature

Clutch

Clutch type	Multiplate oil-bath clutch, anti-hopping
-------------	--

Transmission

Gearbox type	Claw-shift 6-speed transmission with helical-cut splines
Gearbox transmission ratios	1.000 (60:60 teeth), Primary transmission ratio 1.650 (33:20 teeth), Transmission input ratio 2.438 (39:16 teeth), 1st gear 1.714 (36:21 teeth), 2nd gear 1.296 (35:27 teeth), 3rd gear 1.059 (36:34 teeth), 4th gear 0.943 (33:35 teeth), 5th gear 0.848 (28:33 teeth), 6th gear 1.061 (35:33 teeth), Transmission output ratio

Final drive

Type of final drive	Shaft drive with bevel gears
Type of rear suspension	Cast aluminium single swinging arm with BMW Motorrad paralever
Gear ratio of final drive	2.75 (33/12 teeth)

Frame

Frame type	Tubular steel frame with load-bearing drive unit, aluminium rear frame
Type plate location	Frame, front right (beside spring strut)
Position of the Vehicle Identification Number	Frame, front right, on steering head

Chassis and suspension

Front wheel	
Type of front suspension	BMW Telelever, with anti-dive top fork bridge, leading link mounted on engine and telescopic forks, central spring strut supported by leading link and frame
Design of front wheel suspension	Central shock absorber with helical spring
– with Dynamic ESA ^{OE}	Central shock absorber complete with torsion spring and header tank, electrically adjustable de-compression and compression-stage damping
Spring travel, front	120 mm, at wheel
Rear wheel	
Type of rear suspension	Cast aluminium single swinging arm with BMW Motorrad paralever
Type of rear suspension	Central spring strut with coil spring, adjustable rebound stage damping and spring preload
– with Dynamic ESA ^{OE}	Central spring strut with coil spring and reservoir, electrically adjustable rebound-.stage and compression-stage damping, electrically adjustable spring preload
Spring travel at rear wheel	135 mm

Brakes

Front wheel

Type of front brake	Hydraulically actuated twin-disc brake with 4-piston radial monobloc calipers and floating brake discs
Brake-pad material, front	Sintered metal
Brake disc thickness, front	min 4 mm, Wear limit
Play of brake controls (Front brake)	approx. 1.85 mm, at piston

Rear wheel

Type of rear brake	Hydraulically actuated disc brake with 2-piston floating caliper and fixed disc
Brake-pad material, rear	Organic material
Brake disc thickness, rear	min 4.5 mm, Wear limit
Blow-by clearance of the footbrake lever	1 mm, between frame and footbrake lever

Wheels and tyres

Recommended tyre sets	Your authorised BMW Motorrad dealer will be happy to supply an up-to-date list of the approved wheel/tyre combinations, or you can check the information posted on the bmw-motorrad.com website.
Speed category, front/rear tyres	W, required at least: 270 km/h

Front wheel

Front wheel type	Aluminium cast wheel
Front wheel rim size	3.5" x 17"
Tyre designation, front	120/70 - 17
Load index, front tyre	min. 52
Wheel load, front, at unladen weight	139 kg
Permissible wheel load, front	max 177 kg
Permissible front-wheel imbalance	max 5 g

Rear wheel

Rear-wheel type	Aluminium cast wheel
Rear wheel rim size	5.5" x 17"
Tyre designation, rear	180/55 - 17
Load index, rear tyre	min. 70
Wheel load, rear, at unladen weight	135 kg
Permissible wheel load, rear	max 318 kg
Permissible rear-wheel imbalance	max 45 g

Tyre pressures

Tyre pressure, front	2.5 bar, tyre cold
Tyre pressure, rear	2.9 bar, tyre cold

Electrical system

Electrical rating of on-board sockets	max 10 A, Total for all sockets
Fuse box	15 A, Slot 1: Instrument cluster, alarm system (DWA), ignition lock, diagnostic socket, topcase light 7.5 A, Slot 2: Multifunction switch left, tyre pressure control (RDC), audio system
Fuse holder	50 A, Fuse 1: Voltage regulator

Battery

Battery type	AGM (Absorbent Glass Mat) battery
Battery rated voltage	12 V
Battery rated capacity	16 Ah

Spark plugs

Spark plugs, manufacturer and designation	NGK LMAR8D-J
Electrode gap of spark plug	0.8 \pm 0.1 mm, when new 1.0 mm, Wear limit

Lighting

Bulb for high-beam headlight	H1 / 12 V / 55 W
Bulbs for the low-beam headlight	H7 / 12 V / 55 W
Bulb for parking light	W5W / 12 V / 5 W
– with daytime running light ^{OE} or – with Pro Headlight ^{OE}	Lighting rings, integrated into headlight
Bulb for tail light/brake light	LED
Bulbs for flashing turn indicators, front	LED
Bulbs for flashing turn indicators, rear	LED

Anti-theft alarm

Activation time on arming	approx. 30 s
Alarm duration	approx. 26 s
Battery type	CR 123 A

Dimensions

Length of motorcycle	2185 mm
Height of motorcycle	1405 mm, At DIN unladen weight
Width of motorcycle	980 mm, across mirrors
Front-seat height	805...825 mm, Without rider at unladen weight
– with front seat, low ^{OE}	760...780 mm, Without rider at unladen weight
– with front seat, high ^{OE}	830...850 mm, Without rider at unladen weight
Rider's inside-leg arc, heel to heel	1810...1850 mm, Without rider at unladen weight
– with front seat, low ^{OE}	1740...1780 mm, Without rider at unladen weight
– with front seat, high ^{OE}	1875...1915 mm, Without rider at unladen weight

Weights

Vehicle kerb weight	276 kg, Empty DIN weight, ready for operation, fuel tank filled up by 90%, including cases, without OE
Permissible gross weight	495 kg
Maximum payload	219 kg, Without OE

Riding specifications

Starting capability on uphill gradients (at permissible gross weight)	20 %
Top speed	>200 km/h

Service

BMW Motorrad Service	188
BMW Motorrad Mobility services	188
Maintenance work	188
BMW Service	189
Maintenance schedule	191
Confirmation of maintenance work	192
Confirmation of service	206

BMW Motorrad Service

BMW Motorrad has an extensive network of dealerships in place to look after you and your motorcycle in more than 100 countries. Authorised BMW Motorrad dealerships have the technical information and the technical know-how to reliably carry out all maintenance and repair work on your BMW.

You can locate your nearest authorised BMW Motorrad dealership by visiting our website:

bmw-motorrad.com



WARNING

Maintenance and repair work not in compliance with correct procedure

Risk of accident due to consequential damage

- BMW Motorrad recommends having work of this nature carried out on the vehicle by a

specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

In order to help ensure that your BMW is always in optimum condition, BMW Motorrad recommends compliance with the maintenance intervals specified for your motorcycle. Have all maintenance and repair work that is carried out confirmed in the "Service" chapter in this manual. For generous treatment of claims submitted after the warranty period has expired, evidence of regular maintenance is essential.

Your authorised BMW Motorrad dealer can provide information on BMW services and the work undertaken as part of each service.

BMW Motorrad Mobility services

As owner of a new BMW motorcycle, in circumstances in which assistance is required you can benefit from the protection afforded by the various BMW Motorrad mobility services (e.g. Mobile Service, breakdown service, vehicle recovery service). Your authorised BMW Motorrad dealer will be happy to provide information about the mobility services available to you.

Maintenance work

BMW Pre-delivery Check

Your authorised BMW Motorrad dealer conducts the BMW pre-delivery check before handing over the vehicle to you.

BMW Running-in Check

The BMW running-in check has to be performed when the vehicle has covered between 500 km and 1200 km.

BMW Service

The BMW Service is carried out once a year; the extent of servicing can vary, depending on the age of the vehicle and the distance it has covered. Your authorised BMW Motorrad dealer confirms that the service work has been carried out and enters the date when the next service will be due.

Riders who cover long distances in a year might have to bring in their vehicles for service before the next scheduled date. It is to allow for these cases that a maximum odometer reading is entered as well in the confirmation of service. Servicing has to be brought forward if this odo-

meter reading is reached before the next scheduled date for the service.

The service-due indicator in the multifunction display reminds you about one month or 1000 km in advance when the time for a service is approaching, on the basis of the programmed values.

To find out more about service go to:

bmw-motorrad.com/service

The maintenance tasks necessary for your vehicle are set out in the maintenance schedule below:

Maintenance schedule

- 1** BMW Running-in check
- 2** BMW Service standard scope
- 3** Engine-oil change, with filter
- 4** oil change in bevel gears rear
- 5** Check valve clearance
- 6** Replace all spark plugs
- 7** Replace air filter element
- 8** Change brake fluid, entire system
 - a annually or every 10000 km (whichever comes first)
 - b every 2 years or every 20000 km (whichever comes first)
 - c for the first time after one year, then every two years

Confirmation of maintenance work

BMW Motorrad Service, standard scope

The activities in the BMW Motorrad Service standard scope are listed below. The actual scope of maintenance work for your vehicle may differ.

- Performing vehicle test with BMW Motorrad diagnostic system
- Visual inspection of hydraulic clutch system
- Visually inspecting brake pipes, brake hoses and connections
- Checking front brake pads and brake discs for wear
- Checking brake-fluid level, front brakes
- Checking rear brake pads and brake disc for wear
- Checking brake-fluid level, rear brakes
- Checking coolant level
- Checking ease of movement of side stand
- Checking ease of movement of centre stand
- Checking tyre tread depth and tyre pressure
- Check the lights and signalling equipment
- Function test, engine start suppression
- Final inspection and check of roadworthiness
- Setting service-due date and service countdown distance
- Checking battery charge state
- Confirming the BMW service in the on-board literature

BMW Pre-delivery Check

Completed

on _____

Stamp, signature

BMW Running-in Check

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if reached beforehand

Odometer reading _____

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if reached beforehand

Odometer reading _____

Item

BMW Motorrad Service, standard
scope

Yes

No

oil change, engine, with filter

oil change in rear bevel gears

Checking valve clearance

Renewing all spark plugs

Renewing air cleaner insert

Change brake fluid in entire system

Notes

 Stamp, signature

BMW Service

Completed
on _____
Odometer reading _____

Next service
at the latest
on _____
or, if reached beforehand
Odometer reading _____

Item	Yes	No
BMW Motorrad Service, standard scope	<input type="checkbox"/>	<input type="checkbox"/>
oil change, engine, with filter	<input type="checkbox"/>	<input type="checkbox"/>
oil change in rear bevel gears	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Renewing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Renewing air cleaner insert	<input type="checkbox"/>	<input type="checkbox"/>
Change brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Notes

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if reached beforehand

Odometer reading _____

Item

Yes

No

BMW Motorrad Service, standard
scope

oil change, engine, with filter

oil change in rear bevel gears

Checking valve clearance

Renewing all spark plugs

Renewing air cleaner insert

Change brake fluid in entire system

Notes

 Stamp, signature

BMW Service

Completed
on _____
Odometer reading _____

Next service
at the latest
on _____
or, if reached beforehand
Odometer reading _____

Item	Yes	No
BMW Motorrad Service, standard scope	<input type="checkbox"/>	<input type="checkbox"/>
oil change, engine, with filter	<input type="checkbox"/>	<input type="checkbox"/>
oil change in rear bevel gears	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Renewing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Renewing air cleaner insert	<input type="checkbox"/>	<input type="checkbox"/>
Change brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Notes

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if reached beforehand

Odometer reading _____

Item

Yes

No

BMW Motorrad Service, standard
scope

oil change, engine, with filter

oil change in rear bevel gears

Checking valve clearance

Renewing all spark plugs

Renewing air cleaner insert

Change brake fluid in entire system

Notes

 Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if reached beforehand

Odometer reading _____

Stamp, signature

Item

Yes No

BMW Motorrad Service, standard scope

oil change, engine, with filter

oil change in rear bevel gears

Checking valve clearance

Renewing all spark plugs

Renewing air cleaner insert

Change brake fluid in entire system

Notes

BMW Service

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if reached beforehand

Odometer reading _____

Item

Yes

No

BMW Motorrad Service, standard
scope

oil change, engine, with filter

oil change in rear bevel gears

Checking valve clearance

Renewing all spark plugs

Renewing air cleaner insert

Change brake fluid in entire system

Notes

 Stamp, signature

BMW Service

Completed
on _____
Odometer reading _____

Next service
at the latest
on _____
or, if reached beforehand
Odometer reading _____

Item	Yes	No
BMW Motorrad Service, standard scope	<input type="checkbox"/>	<input type="checkbox"/>
oil change, engine, with filter	<input type="checkbox"/>	<input type="checkbox"/>
oil change in rear bevel gears	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Renewing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Renewing air cleaner insert	<input type="checkbox"/>	<input type="checkbox"/>
Change brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Notes

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if reached beforehand

Odometer reading _____

Item

Yes

No

BMW Motorrad Service, standard
scope

oil change, engine, with filter

oil change in rear bevel gears

Checking valve clearance

Renewing all spark plugs

Renewing air cleaner insert

Change brake fluid in entire system

Notes

 Stamp, signature

BMW Service

Completed
on _____
Odometer reading _____

Next service
at the latest
on _____
or, if reached beforehand
Odometer reading _____

Item	Yes	No
BMW Motorrad Service, standard scope	<input type="checkbox"/>	<input type="checkbox"/>
oil change, engine, with filter	<input type="checkbox"/>	<input type="checkbox"/>
oil change in rear bevel gears	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Renewing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Renewing air cleaner insert	<input type="checkbox"/>	<input type="checkbox"/>
Change brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Notes

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if reached beforehand

Odometer reading _____

Item

Yes

No

BMW Motorrad Service, standard
scope

oil change, engine, with filter

oil change in rear bevel gears

Checking valve clearance

Renewing all spark plugs

Renewing air cleaner insert

Change brake fluid in entire system

Notes

 Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if reached beforehand

Odometer reading _____

Stamp, signature

Item

BMW Motorrad Service, standard scope

oil change, engine, with filter

oil change in rear bevel gears

Checking valve clearance

Renewing all spark plugs

Renewing air cleaner insert

Change brake fluid in entire system

Yes

No

Notes

Confirmation of service

The table is intended as a record of maintenance and repair work, the installation of optional accessories and, if appropriate, special campaign (recall) work.

Item	Odometer reading	Date

Item	Odometer reading	Date

Appendix

Certificate for electronic immobiliser	210
Certificate for remote control	212
Certificate for Keyless Ride	216
Certificate for tyre pressure control (RDC)	218

FCC Approval

Ring aerial in the ignition switch



To verify the authorization of the ignition key, the electronic immobilizer exchanges information with the ignition key via the ring aerial.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. ◀

Approbation de la FCC

Antenne annulaire présente dans le commutateur d'allumage



Pour vérifier l'autorisation de la clé de contact, le système d'immobilisation électronique échange des

informations avec la clé de contact via l'antenne annulaire.

Le présent dispositif est conforme à la partie 15 des règles de la FCC. Son utilisation est soumise aux deux conditions suivantes :

- (1) Le dispositif ne doit pas produire d'interférences nuisibles, et
- (2) le dispositif doit pouvoir accepter toutes les interférences extérieures, y compris celles qui pourraient provoquer une activation inopportune.



Toute modification qui n'aurait pas été approuvée expressément par l'organisme responsable de l'homologation peut annuler l'autorisation accordée à l'utilisateur pour utiliser le dispositif. ◀

Certifications

Remote Control for central locking system



Česky

Meta System S.p.A. tímto prohlašuje, že tento PF240009 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Dansk

Undertegnede Meta System S.p.A. erklærer herved, at følgende udstyr PF240009 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Deutsch

Hiermit erklärt Meta System S.p.A., dass sich das Gerät PF240009 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

Eesti

Käesolevaga kinnitab Meta System S.p.A. seadme PF240009 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

English

Hereby, Meta System S.p.A., declares that this PF240009 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Español

Por medio de la presente Meta System S.p.A. declara que el PF240009 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Certifications

Ελληνική

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Meta System S.p.A. ΔΗΛΩΝΕΙ ΟΤΙ PF240009 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Français

Par la présente Meta System S.p.A. déclare que l'appareil PF240009 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Italiano

Con la presente Meta System S.p.A. dichiara che questo PF240009 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Latviski

Ar šo Meta System S.p.A. deklarē, ka PF240009 atbilst Direktīvas 1999/5/ΕΚ būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Lietuvių

Šiuo Meta System S.p.A. deklaruoja, kad šis PF240009 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Nederlands

Hierbij verklaart Meta System S.p.A. dat het toestel PF240009 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Malti

Hawnhekk, Meta System S.p.A., jiddikjara li dan PF240009 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Magyar

Alulírott, Meta System S.p.A. nyilatkozom, hogy a PF240009 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Polski

Niniejszym Meta System S.p.A. oświadcza, że PF240009 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Português

Meta System S.p.A. declara que este PF240009 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Certifications

Slovensko

Meta System S.p.A. izjavlja, da je ta PF240009 v skladi z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Slovensky

Meta System S.p.A. týmto vyhlasuje, že PF240009 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Suomi

Meta System S.p.A. vakuuttaa täten että PF240009 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Svenska

Härmed intygar Meta System S.p.A. att denna PF240009 står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Íslenska

Hér með lýsir Meta System S.p.A. yfir því að PF240009 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Norsk

Meta System S.p.A. erklærer herved at utstyret PF240009 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

USA, Canada

Product name: TX BMW MR FCC ID: P3098400 IC:4429A - TXBMWMR

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Declaration Of Conformity

R&TTE Declaration Of Conformity (DoC)

CE0470

We:

Meta System S.p.A.

with the address:

Via Majakovskij 10 b/c/d/e
42124 Reggio Emilia -Italy

Declare

Under own responsibility that the product:

TX BMW MR

To which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC).

This product is in conformity with the following standards:

Health & Safety (art.3.1)

EN 60950-1

EMC (art.3.2)

ETSI EN 301 489-1/-3

Spectrum

ETSI EN 300 220 - 2

Human exposure

EN 62311

According to Directive 1999/5/CE

Reggio Emilia , 14/07/2010

Technical Director
Lasagni Cesare



Certifications

BMW Keyless Ride ID Device



USA, Canada

Product name: BMW Keyless Ride ID Device
FCC ID: YGOHUF5750
IC: 4008C-HUF5750

Canada:

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

USA:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Declaration Of Conformity

We declare under our responsibility that the product


BMW Keyless Ride ID Device (Model: HUF5750)

complies with the appropriate essential requirements of the article 3 of the R&TIE and the other relevant provisions, when used for its intended purpose. Applied Standards:

1. Health and safety requirements contained in article 3 (1) a)
 - EN 60950-1:2006+A11:2009+A1:2010+A12:2011; Information technology equipment- Safety
2. Protection requirements with respect to electromagnetic compatibility article 3 (1) b)
 - EN 301 489-1 (V1 .9.2, 09/2011), Electromagnetic compatibility and radio spectrum matters (ERM); Electromagnetic compatibility (EMC) standard for radio equipment and services; Part 1: Common technical requirements
 - EN 301 489-3 (V1.4.1, 08/2002) Electromagnetic compatibility and radio spectrum matters (ERM); Electromagnetic compatibility (EMC) standard for radio equipment and services; Part 3: Specific conditions for short range devices (SRD) operating on frequencies between 9 kHz and 40 GHz
3. Means of the efficient use of the radio frequency spectrum article 3 (2)
 - EN 300 220-1 & -2 (V2.4.1, 05/2012), electromagnetic compatibility and radio spectrum matters (ERM); Short range devices (SRD); Radio equipment to be used in the 25 MHz to 1000 MHz frequency range with power levels ranging up to 500 mW;
Part 1: Technical characteristics and test methods.
Part 2: Harmonized EN covering essential requirements under article 3.2 of the R&TIE directive

The product is labeled with the CE marking: **CE**

Velbert, October 15th, 2013



Benjamin A. Müller
Product Development Systems
Car Access and Immobilization – Electronics
Huf Hüsbeck & Fürst GmbH & Co. KG
Steeger Straße 17, D-42551 Velbert

Certification Tire Pressure Control (TPC)

FCC ID: MRXBC54MA4
IC: 2546A-BC54MA4

FCC ID: MRXBC5A4
IC: 2546A-BC5A4

This device complies with Part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

A

Abbreviations and symbols, 6

ABS

Engineering details, 108

Self-diagnosis, 96

Status indicators, 36

Accessories

General instructions, 156

Actuality, 7**Ambient temperature**

Outside temperature

warning, 29

Reading, 40

Anti-theft alarm

Indicator light, 18

operate, 70

Warning, 32

ASC

Control, 15

operate, 63

Self-diagnosis, 97

Status indicators, 36

Auxiliary headlights

operate, 53

Average values

reset, 62

B**Battery**

Charging battery when
connected, 148

Charging battery when
disconnected, 149

Indicator light for battery
charge voltage, 34

Installation, 150

Maintenance instructions, 147

Removal, 149

Technical data, 183

Warning for battery voltage
low, 33

Brake fluid

Checking fluid level, front, 126

Checking fluid level, rear, 127

Reservoir, front, 13

Reservoir, rear, 13

Brake pads

Checking front, 124

Checking rear, 125

Running in, 98

Brakes

ABS Pro in detail, 110

ABS Pro depending on riding
mode, 100

Adjusting handlebar lever, 86

Checking function, 123

Safety instructions, 99

Technical data, 180

C**Cases**

operate, 157

Central locking

operate, 78

Warning for lock status, 38

Checklist, 94**Clock**

Adjusting, 60

- Clutch
 - Adjusting handlebar lever, 86
 - Fluid reservoir, 11
 - Technical data, 177
- Confirmation of maintenance work, 192
- Coolant
 - Checking fill level, 128
 - Filling level indicator, 13
 - Topping up, 129
 - Warning for overtemperature, 30
- Cruise-control system
 - Control, 15
 - operate, 67
- D**
- Date
 - Adjusting, 60
- Daytime riding lights
 - automatic daytime riding light, 55
 - Manual daytime riding light, 54
- Diagnostic connector
 - Loosen, 153
 - secure, 153
- Dimensions
 - Technical data, 185
- DWA
 - Technical data, 184
- E**
- Electrics
 - Technical data, 183
- Emergency off switch (kill switch), 17
 - Operation, 52
- Emissions warning light, 30
- Engine
 - Indicator light for engine electronics, 31
 - Malfunction indicator lamp, 30
 - starting, 95
 - Technical data, 176
- Engine oil
 - Checking fill level, 122
 - oil dipstick, 13
 - oil filler opening, 13
 - oil level, 40
 - Technical data, 175
 - Topping up, 123
- Warning for engine oil level, 30
- Equipment, 7
- ESA
 - Control, 15
 - Engineering details, 113
 - operate, 64
- F**
- Frame
 - Technical data, 178
- Front seat
 - Adjusting seat height, 75
 - Height adjuster, 14
 - install, 74
 - Installation, 75
 - Lock, 11
 - remove, 74
- Front-wheel stand
 - Installing, 121
- Fuel
 - Filler neck, 11
 - Fuel grade, 102
 - Refuelling, 102
 - refuelling with Keyless Ride, 103, 104
 - Technical data, 175

Fuel reserve
Range, 39
Warning, 38

Fuses
Position on the vehicle, 14
replacing, 151

G

General views
Indicator and warning lights, 20
Instrument panel, 18
Left multifunction switch, 15
Left side of vehicle, 11
Multifunction display, 23
Right multifunction switch, 17
Right side of vehicle, 13
Underneath the seat, 14

H

Hazard warning flashers
Control, 15
operate, 56
Headlight
Beam throw, 84
Heated handlebar grips
operate, 72

Hill Start Control, 118
Engineering details, 118
Hill Start Control, 69
operate, 69
Horn, 15

I

Ignition
Switching off, 45
Switching on, 44
Immobiliser
Emergency key, 48
Spare key, 45
Warning, 29
Instrument panel
Adjusting, 85
Ambient-light brightness
sensor, 18
Overview, 18

J

Jump-start, 146

K

Keyless Ride
Battery of the radio-operated
key is empty, 49
Electronic immobiliser EWS, 48
Fuel filler cap, unlocking, 103,
104
Lock the handlebars, 46
Loss of the radio-operated
key, 49
Switching off ignition, 47
Switching on ignition, 47
Warning, 29, 30
Keys, 44, 46

L

Lighting
High-beam headlight, 141
LED auxiliary headlights,
replacing, 146
LED rear light, replacing, 145
Low-beam headlight, 139
Side light, 143
Technical data, 184

- Warning for bulb failure, 32
- Waveguide rings, replacing, 146
- Lights
 - automatic daytime riding light, 55
 - Control, 15
 - Headlight flasher, 53
 - High-beam headlight, 53
 - Low-beam headlight, 52
 - Manual daytime riding light, 54
 - Parking lights, 53
 - Side light, 52
- Luggage
 - Instructions for loading, 92
- M**
 - Maintenance
 - General instructions, 120
 - Maintenance schedule, 191
 - Maintenance intervals, 188
 - Mirrors
 - Adjusting, 84
 - Mobility services, 188
- Motorcycle
 - care, 167
 - cleaning, 167
 - Lashing, 105
 - Laying up, 170
 - parking, 101
- Multifunction display, 18
 - Control, 15
 - Meaning of symbols, 21
 - Overview, 23
 - Select display, 57
 - Settings, 60
- Multifunction switch
 - General view, left side, 15
 - General view, right side, 17
- N**
 - Navigation devices
 - install, 162
 - operate, 164
 - Removal, 163
- O**
 - Odometer and tripmeters
 - operate, 63
- On-board computer
 - operate, 61
- P**
 - Parking, 101
 - Power socket
 - Notes on use, 156
 - Position on the vehicle, 13
 - Pre-Ride-Check, 95
- R**
 - RDC
 - Adhesive label for rim, 133
 - Engineering details, 115
 - Reading, 40
 - Warnings, 34
 - Rear seat
 - install, 76
 - Installation, 77
 - remove, 76
 - Rear-wheel drive
 - Technical data, 178
 - Refuelling, 102
 - with Keyless Ride, 103, 104

- Remote control
 - registration, 80
 - Replacing battery, 51, 82
 - synchronising, 81
- Rev. counter, 18
- Riding mode
 - Adjusting, 65
 - Engineering details, 113
- Riding specifications
 - Technical data, 186
- Running gear
 - Technical data, 179
- Running in, 97

S

- Safety instructions
 - for brakes, 99
 - for riding, 92
- Seat heating
 - Control, 11
 - operate, 72
- Service, 188
 - Warning, 38
- Service-due indicator, 39

- Shift assistant, 98, 116
 - Engineering details, 116
 - Gear not calibrated, 38
 - Riding, 98
- Silencer
 - Securing silencer, 132
 - Silencer, swinging out, 131
- Spark plugs
 - Technical data, 183
- Speedometer, 18
- Spring preload
 - Adjusting, 87
- Starting, 95
 - Control, 17
- Steering lock
 - Locking, 44
- Stowage compartment
 - operate, 78
 - Position on the vehicle, 11, 13
- Symbols
 - Meaning, 21

T

- Technical data
 - Anti-theft alarm, 184
 - Battery, 183
 - Brakes, 180
 - Bulbs, 184
 - Chassis and suspension, 179
 - Clutch, 177
 - Dimensions, 185
 - Electrical system, 183
 - Engine, 176
 - Engine oil, 175
 - Final drive, 178
 - Frame, 178
 - Fuel, 175
 - Riding specifications, 186
 - Spark plugs, 183
 - Standards, 7
 - Transmission, 177
 - Weights, 186
 - Wheels and tyres, 181
- Telltale lights, 18
 - Overview, 20
- Threaded fasteners, 173

- Toolkit
 - Contents, 120
 - Position on the vehicle, 14
 - Topcase
 - operate, 159
 - Torques, 173
 - Traction control
 - ASC, 111
 - Transmission
 - Technical data, 177
 - Troubleshooting chart, 172
 - Turn indicators
 - Control, 15
 - operate, 56
 - Type plate
 - Position on the vehicle, 13
 - Tyres
 - Checking inflation pressure, 130
 - Checking tread depth, 130, 131
 - Pressures, 182
 - Recommendation, 133
 - Running in, 98
 - Technical data, 181
 - Top speed, 93
- V**
- Vehicle
 - Restoring to use, 170
 - Vehicle Identification Number
 - Position on the vehicle, 13
- W**
- Warning lights, 18
 - Overview, 20
 - Warnings
 - ABS, 36
 - Anti-theft alarm, 32
 - ASC, 36
 - Battery charge voltage, 34
 - Bulb defect, 32
 - Central locking, 38
 - Coolant temperature, 30
 - Engine electronics, 31
 - Engine oil level, 30
 - Fuel reserve, 38
 - Gear not calibrated, 38
 - Immobiliser, 29
 - Malfunction indicator lamp, 30
 - Mode of presentation, 24
 - Outside temperature warning, 29
 - RDC, 34
 - Service, 38
 - Undervoltage, 33
 - Warnings, overview, 25
 - Weights
 - Technical data, 186
 - Wheels
 - Change of size, 133
 - Checking rims, 130
 - Installing front wheel, 136
 - Installing the rear wheel, 138
 - Removing front wheel, 134
 - Removing rear wheel, 138
 - Technical data, 181
 - Windscreen
 - Adjusting, 84
 - Control, 15

Details described or illustrated in this booklet may differ from the vehicle's actual specification as purchased, the accessories fitted or the national-market specification. No claims will be entertained as a result of such discrepancies.

Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances.

The right to modify designs, equipment and accessories is reserved.

Errors and omissions excepted.

© 2016 Bayerische Motoren Werke Aktiengesellschaft
80788 Munich, Germany
Not to be reproduced by any means whatsoever, wholly or in part, without the written permission of BMW Motorrad, After Sales.

Original rider's manual, printed in Germany.

